



COMPACTION & RECYCLING SOLUTIONS

www.marathonequipment.com

1-877-258-1105

**OPERATION, MAINTENANCE,
AND INSTALLATION MANUAL
TIEger[®] Series Auto-Tie Balers
(PC, WC, and EWC Models)**



1-800-633-8974 www.marathonequipment.com

MARATHON[®] Compaction & Recycling Solutions

• OMI Manual No. 0064-1, Rev. 07/14

Table of Contents

| | |
|---|------------|
| 1 - OPERATION | 1-1 |
| Introduction | 1-2 |
| Specifications | 1-3 |
| Pre-Operation Instructions..... | 1-5 |
| Emergency Stop Locations..... | 1-6 |
| Typical Control Panel and Panel Box..... | 1-7 |
| Standard Operation - Baler Start Up | 1-8 |
| Baler Start Up | 1-8 |
| Standard Automatic Operation | 1-9 |
| Automatic Operation Mode | 1-9 |
| Manual Operation Mode | 1-9 |
| Procedure For Manually Tying Bale | 1-10 |
| Making a Bale..... | 1-11 |
| Automatic Mode..... | 1-11 |
| Manual Mode..... | 1-11 |
| Shutdown | 1-11 |
| Security Screen | 1-12 |
| Main Menu Screen | 1-13 |
| Manual Motor Start Screen | 1-14 |
| Auto Menu Screen | 1-15 |
| Manual Menu Screens | 1-16 |
| Manual Menu Screen - 2 | 1-17 |
| Manual Menu Screen - 3 | 1-18 |
| Fault Screen | 1-19 |
| Major Fault Screen | 1-20 |
| Fault List..... | 1-21 |
| General Setup Screens..... | 1-22 |
| General Setup Screen 2 | 1-23 |
| General Setup Screen 3 | 1-24 |
| General Setup Screen 4 | 1-25 |
| Grade Setup Screens | 1-26 |
| Grade Setup Screen 2..... | 1-27 |
| Grade Setup Screen 3..... | 1-28 |
| Grade Setup Screen 4..... | 1-29 |
| Grade Setup Screen 5..... | 1-30 |
| Grade Setup Screen 6..... | 1-31 |

| | |
|--|------------|
| Grade Setup Screen 7..... | 1-32 |
| Grade Setup Screen 8..... | 1-33 |
| Diagnostics Menus..... | 1-34 |
| Diagnostics Menu 2 | 1-35 |
| Diagnostics Menu 3 | 1-35 |
| Input/Output Status Screens | 1-36 |
| Input/Output Status Screen 2 | 1-36 |
| Input/Output Status Screen 3..... | 1-37 |
| Input/Output Status Screen 4 | 1-37 |
| Data Screens..... | 1-38 |
| Data Screen 2 | 1-39 |
| Data Screen 3 | 1-40 |
| Data Screen 4 | 1-41 |
| Bale Length Counter | 1-42 |
| Setting Bale Length Counter | 1-42 |
| Bale Plug Instructions | 1-43 |
| Wire Box Loading | 1-45 |
| Typical Wire Box Installation..... | 1-45 |
| General Overview of the Auto-Tie Cycle..... | 1-46 |
| Wire Routing and Installation..... | 1-46 |
| Adjusting the Wire-Tensioner..... | 1-46 |
| Wire Installation & Adjustment..... | 1-47 |
| Wire-Tier Side | 1-47 |
| Wire Installation & Adjustment Opposite Wire-Tier Side | 1-48 |
| Spring Feeder Adjustment - Opposite Wire-Tier Side | 1-48 |
| Inserter Needle Risers | 1-49 |
| Wire Installation - Initial Wire Connection..... | 1-49 |
| Decal Diagram | 1-50 |
| Decal Description | 1-52 |
| Warning Decal Requirements | 1-52 |
| Decal Images | 1-53 |
| 2 - MAINTENANCE | 2-1 |
| Lock-Out & Tag-Out Instructions | 2-2 |
| Marathon Equipment's Service Department..... | 2-3 |
| Periodic Maintenance | 2-4 |
| After Start-Up | 2-4 |
| Daily (Operator) | 2-4 |
| Weekly (Operator) | 2-4 |
| Monthly (Service Personnel) | 2-5 |

| | |
|---|------------|
| Semi-Annually (Service Personnel) | 2-5 |
| Annually (2000 hours of operation) | 2-5 |
| Annually | 2-6 |
| Recommended Oils..... | 2-6 |
| Power Unit Drawing 30 HP..... | 2-7 |
| Power Unit Reference Numbers 30 HP | 2-8 |
| Power Unit Drawing - 2 X 30 HP Motors..... | 2-11 |
| Power Unit Reference Numbers - 2 x 30 HP..... | 2-13 |
| Switch Location Diagram | 2-17 |
| Switch Description..... | 2-18 |
| Twister Head Clock Adjustment - Left Hand Assembly | 2-19 |
| Adjustment Procedure: | 2-19 |
| Twister Head Clock Adjustment - Right Hand Assembly | 2-20 |
| Adjustment Procedure: | 2-20 |
| Electrical Schematic..... | 2-21 |
| Electrical Charts..... | 2-21 |
| Spare Parts List | 2-22 |
| Inserter Needle Assembly..... | 2-23 |
| Inserter Needle Assembly - Parts List..... | 2-24 |
| Twister Head Assembly | 2-25 |
| Twister Head Assembly - Parts List | 2-26 |
| Drive Assembly For Twister Head | 2-27 |
| Drive Assembly For Twister Head - Parts List | 2-28 |
| Inserter Frame Assembly | 2-29 |
| Inserter Frame Assembly Parts List..... | 2-31 |
| Inserter/Twister Covers | 2-33 |
| Inserter/Twister Covers Parts List..... | 2-35 |
| Wire Feed Components | 2-37 |
| Hydraulic Wire Guides - Twister Side..... | 2-38 |
| Wire Tensioner Components | 2-39 |
| Wire Feed, Guides, & Tensioner Parts List | 2-40 |
| Troubleshooting | 2-43 |
| Troubleshooting - Power Unit | 2-43 |
| Troubleshooting - Wire-Tier | 2-45 |
| Troubleshooting - Baler | 2-45 |
| 3 - INSTALLATION..... | 3-1 |
| General Requirements | 3-2 |
| Concrete Pad or Floor | 3-2 |

| | |
|-------------------------------|----------|
| Anchoring | 3-2 |
| Decals | 3-2 |
| Anchoring Machine | 3-3 |
| Electrical Installation | 3-4 |
| Grounding Instructions | 3-4 |
| Start-Up Instructions | 3-5 |
| INDEX..... | 1 |

1 - OPERATION

Introduction

Thank you for purchasing a TIEger® Auto-Tie Baler.

This product is designed to give you reliable service and superior performance for years to come. The purpose of this manual is to provide the owner and/or operators with the necessary information to properly and safely install, operate, and maintain the baler. Also included are sections regarding troubleshooting and service procedures. The manual is not intended as a primary training source, but as a reference guide for authorized, trained personnel. Each person involved in the operation, maintenance, and installation of the machine should read and thoroughly understand the instructions in this manual and follow ALL warnings.

Employers involved in the operation, maintenance, and installation of the baler should also read and understand the most current version of the following applicable standards:

ANSI Standard No. Z245.5, "Safety Requirements For Baling Equipment"

A copy of this standard may be obtained from ANSI (www.ansi.org):

25 West 43rd Street

New York, NY 10036

OSHA Title 29 CFR, Part 1910.147

"The Control of Hazardous Energy (Lock-Out and Tag-Out)" (www.osha.gov)

Any service or repair instructions contained in this manual should be performed by factory authorized personnel only.

If you should need assistance with your baler, please contact your distributor. When contacting your distributor, you will need to provide:

- Serial Number: _____
- Installation Date: _____
- Electrical Schematic Number: _____

If you have any safety concerns with the equipment, or need further information, please contact us at 1-800-633-8974 or:


Marathon Equipment Company

Attn: Field Service Department

P.O. Box 1798

Vernon, AL 35592-1798

Specifications



Specifications (Continued)

| | (All units in inches) | PC Models | | | | WC Models | | EWC Models | |
|---|-----------------------|-----------|--------|--------|--------|-----------|--------|------------|--------|
| | Model # | 115-32 | 150-32 | 115-44 | 150-44 | 150-60 | 150-72 | 150-60 | 150-72 |
| A | Charge Chamber Length | 30 | 30 | 49 | 49 | 65 | 77 | 65 | 77 |
| B | Charge Chamber Width | 37 | 37 | 30 | 30 | 42 | 42 | 48 | 48 |
| C | Bale Width | 30 | 30 | 30 | 30 | 42 | 42 | 48 | 48 |
| D | Bale Height | 42 | 42 | 42 | 42 | 42 | 42 | 42 | 42 |
| E | Feed Hopper Width | 28 | 28 | 28 | 28 | 39 | 39 | 45 | 45 |
| F | Tensioner Height | 80 | 80 | 80 | 80 | 81 1/4 | 81 1/4 | 81 1/4 | 81 1/4 |
| G | Body Height | 52 | 52 | 52 | 52 | 55 | 55 | 55 | 55 |
| H | Body Length | 278 | 278 | 302 | 302 | 356 | 380 | 356 | 380 |
| I | Feed Hopper Length | 32 | 32 | 44 | 44 | 60 | 72 | 60 | 72 |
| J | Overall Width | 157 | 157 | 157 | 157 | 186 | 186 | 186 | 186 |
| K | Tensioner Width | 72 1/4 | 72 1/4 | 72 1/4 | 72 1/4 | 84 1/4 | 84 1/4 | 90 1/4 | 90 1/4 |

Pre-Operation Instructions

Warning: Do not operate baler until operating instructions are thoroughly understood. Wear safety glasses and gloves when operating this equipment.



Stay clear of all internal baler parts and all moving external baler parts when in operation. Failure to do so could result in serious personal injury or death!

Never enter any part of baler unless the disconnect switch has been turned off, padlocked, and all stored energy sources have been removed. See **"Lock-Out & Tag-Out Instructions"** on page 2-2.

Before starting baler, be sure no one is inside. Be certain that everyone is clear of all operation points and pinch point areas before starting.

This baler is controlled by photocells and will start automatically when photocells detect ANY OBJECTS in the charge box.


The compression ram in this baler travels at a very fast speed. Stand clear of the baler when in operation.



Employers should allow only authorized and thoroughly trained personnel to operate this baler.

This baler is equipped with a key operated locking system. Keys should be in possession of only authorized personnel. Federal regulation prohibits operation by persons under 18 years of age. Turn off and remove the key after use.

The baler hydraulic system operates at high pressures and at high temperatures. If you suspect have a leak, **do not check with your hands** and avoid contact with piping, hoses, and cylinders.




ONLY AUTHORIZED PERSONNEL SHOULD BE ALLOWED INSIDE PANEL BOX. The panel box contains high voltage components. See **"Lock-Out & Tag-Out Instructions"** on page 2-2.


Emergency Stop Locations

In case of emergency, push any one of three red mushroom-head stop buttons on baler (see diagram below for locations). Make sure all personnel operating baler know where all stop buttons are located. Make sure area around each stop button is clean and free of any debris or operator hazards. Check operation of each stop button as outlined in the Maintenance section of this manual.

All equipment in the processing stream of baler should have emergency stop buttons located for easy operator access. These stop buttons should be connected so as to shut down all power to baler when depressed.



Typical Control Panel and Panel Box



* Touch Screen Instructions begin on **"Security Screen"** on page 1-12.

Standard Operation - Baler Start Up



IN CASE OF EMERGENCY:

Push the large RED button to STOP


Prior to start-up of the baler each day, check the items found in the "DAILY" list in **"Periodic Maintenance" on page 2-4.**

Note: The TIEger® Auto-Tie Baler features an ANSI Z245.5 - 5.10 compliant start-up alarm that is both audible and visible during the activation of the baler motor(s).

Standard operation includes baler start-up for Manual and Automatic Operation.

Baler Start Up

- 1) Check work area and make sure that all personnel are clear of baler.
- 2) Turn electrical disconnect to "ON" position.
- 3) Insert CONTROL key and rotate switch to "ON" position.
- 4) Make sure all Emergency Stop Buttons are pulled out.
- 5) Touch the "SAFETY RELAY RESET" button. (Allow for a brief delay for control processor to initialize).
- 6) Touch "ACK ALL" (acknowledge all) and "Reset" on touch screen to clear alarm screen. The screen will change to Main Menu.
- 7) Touch and hold "MOTOR START" button for 20 seconds.
 - a) Both an audible and visual start-up alarm will energize for 5 seconds.
 - b) After 5 seconds, the audible alarm stops and the visual alarm continues for an additional 15 seconds.
 - c) The main motor(s) will start after the 20-second delay and the operator should remove their finger from "Motor Start" button.



START-UP ALARM

(Mounted on Control Panel)

This completes the BALER START UP sequence.

Touch Screen Instructions begin on **"Security Screen" on page 1-12.**

Standard Automatic Operation

Automatic Operation Mode

- 1) Start the baler per start-up procedures on the previous page.
- 2) Touch the "MANUAL MODE" button and the screen will advance to "MANUAL-MODE-SCREEN".
- 3) Touch the "RAM REVERSE" button until the ram is fully retracted.
- 4) Touch the "MAIN MENU" button.
- 5) Touch the "AUTO MODE" button and the screen will advance to the "AUTO MODE-SCREEN". Touch the "AUTO MODE" button and the baler will automatically cycle when the designated photocell is blocked by an incoming product.
- 6) Touch the CONVEYOR "AUTO" button, if you want the baler to control the flow of material. You may control the flow of material manually by touching the CONVEYOR "ON - OFF" button as required. (Optional controls)
- 7) Touch the "MANUAL MODE", "MAIN MENU", or "CYCLE STOP" button to end AUTO MODE. To resume AUTO MODE, you will have to begin at step 1 of this procedure.

Manual Operation Mode

- 1) Start the baler per start-up procedures on the previous page.
- 2) Touch the "MANUAL MODE" button and the screen will advance to the "MANUAL MODE SCREEN".
- 3) Touch the "RAM REVERSE" or the "RAM FORWARD" button for manual ram operation.

Note: The manual controls will lock if not moved in 60 seconds. If this happens, press the POWER ON button to reset the timer.

Touch Screen Instructions begin on **"Security Screen" on page 1-12.**

Procedure For Manually Tying Bale

Note: Baler must be in operation and in "MANUAL MODE" and on the "MANUAL MENU" to perform this function.

- 1) Press the "TIE CYCLE" button.
- 2) Press and hold "RAM EXTEND" until "RAM EXTENDED" illuminates and "RAM AT TIE POSITION" illuminates.
- 3) Press the "GO TO "MANUAL TIE" button.
- 4) Press and hold "NEEDLES IN" until the needles are fully extended.
- 5) Press and hold "NEEDLES OUT" until the needles are fully retracted.
- 6) Press and hold "TWISTER IN" until the twister head is fully extended.
- 7) Press and hold "TWIST" until all rotation stops.
- 8) Press "TWISTER CUT POSITION".
- 9) Press and hold "TWISTER OUT" until the twister head is fully retracted (this will cut the wires).
- 10) Press "TWIST" once. This will return spin heads back to the home position.
- 11) Press "TWISTER IN". Then press "TWISTER OUT" until the twister head is fully retracted to ensure no wires are in the spin heads.
- 12) Press "Manual Ram" to go back to the manual menu.
- 13) Press and hold "RAM RETRACT" until "RAM RETRACTED" illuminates.
- 14) Press the "MAIN MENU" button.
- 15) Press the "AUTO MENU" button.

Making a Bale



IN CASE OF EMERGENCY:

Push the large RED button to STOP

Warning: Do not operate baler until operating instructions are thoroughly understood.

This baler can be operated in either automatic or manual mode.

Automatic Mode

- 1) Insert the key into the keyswitch and turn to the ON position.
- 2) Depress the PHOTOCCELL ON pushbutton. The baler warning alarm sounds for 5 seconds, the rotating beacon light flashes for 20 seconds, then the power unit starts. From this point, the ram starts automatically any time the photocell senses that the feed hopper/charge box has ANY OBJECT in it. If 15 minutes elapses without a cycle being initiated by the photocell or without operation of any of the pushbuttons, the power unit will shut down.

Warning: In this mode, the power unit will restart the ram automatically any time the photocell detects ANY OBJECT in the charge box.

- 3) Feed materials into the baler. When a bale is completed, the BALE MADE light comes on, the buzzer sounds, and the unit shuts down automatically. Bale tie off and ejection instructions are on the next page.

Manual Mode

- 1) Insert the key into the keyswitch and turn it to the ON position.
- 2) To bale material in the Manual Mode, first completely fill the charge box with material.
- 3) Depress and hold the AUTOCYCLE pushbutton until the power unit starts. The baler will cycle one time (one complete extend and retract of the ram) and shut down.
- 4) Repeat steps 2-3 until BALE MADE light comes on and the buzzer sounds. The closed-end baler can also be operated using the MANUAL MODE pushbutton along with the FORWARD or REVERSE to create a bale.

Shutdown

In either the Automatic Mode or the Manual Mode, to shut down the baler, depress the EMERGENCY STOP pushbutton. Turn the keyswitch to the OFF position and remove the key. Do not enter the baler for any reason until you perform the **"Lock-Out & Tag-Out Instructions" on page 2-2.**

Security Screen



The image shows a security screen interface for Marathon Compaction & Recycling Solutions. At the top, there are three blue buttons: "LOGIN", "Return", and "LOGOUT". In the center, there is a large white box containing the Marathon logo, which consists of a red stylized 'M' shape with the word "MARATHON" in bold black letters and a registered trademark symbol. Below the logo, the text "COMPACTION & RECYCLING SOLUTIONS" is displayed. At the bottom of this central box, there is a black bar with the website "www.marathonequipment.com" on the left and the phone number "1-800-633-8974" on the right. Below the central box, there are two blue buttons: "NEW PASSWORD" and "VERIFY PASSWORD". To the left of these buttons, there is a blue box containing ten hash symbols "#####".

Login - Press after entering the password to login to the interface.

Return - Press to return to the main menu (see next page).


Logout - Press when operator or supervisor is ready to logout of the interface.

- Press to select either "operator" or "supervisor" as usernames. once selected, a numeric keypad is displayed for you to type in your password. Default passwords are "1234" for operators and "8710" for supervisors. These may be changed by selecting "New Password".

New Password - Allows operator or supervisor to choose a new password.

Verify Password - Re-enter new password to verify and save.

Main Menu Screen



Cannot extend needles. Twister head not retracted - The yellow info/error window explains the interruption of the process.

Go To General Setup - Login as "supervisor" to access General Setup. Refer to "**General Setup Screens**" on page 1-22.

Go To Grade Setup - Press button to go to Grade Setup. Refer to "**Grade Setup Screens**" on page 1-26.

Go To Diagnostics - Press button to go to Diagnostics. Refer to "**Diagnostics Menus**" on page 1-34.

Go To Data - Press button to go to the Data screen. Refer to "**Data Screens**" on page 1-38.

Go To Security - Press to go back to the Security/Login screen.

Go To Manual Start - Press to go to the Manual Start screen where you can manually start the motor(s).

Motor Off - The blue info window indicates the status of motors.


Master Start - Press and hold for 20 seconds to start motors. See the countdown in the blue info window.

Master Stop - Press to stop all motors in operation.

Manual Mode - Press to go to the Manual Menu screen. Refer to "**Manual Menu Screens**" on page 1-16.

Auto Mode - Press to start the Auto Mode.

Manual Motor Start Screen



Return To Main Menu - Press this button to go to the Main Menu screen.

All Motors Are On - Indicator screen that displays the status of the motor(s).

Cir Pump Start - Press this button to start the circulating pump.

Cir Pump Stop - Press this button to stop the circulating pump.


Motor 1 Start - Press this button to start Motor #1.

Motor 1 Stop - Press this button to stop Motor #1.

Motor 2 Start - Press this button to start Motor #2.

Motor 2 Stop - Press this button to stop Motor #2.

Auto Menu Screen



Cannot extend needles. Twister head not retracted - The yellow info/error window explains the interruption of process.

Go To General Setup - Login as "supervisor" to access General Setup. Refer to **"General Setup Screens" on page 1-22.**

Go To Grade Setup - Press button to go to Grade Setup. Refer to **"Grade Setup Screens" on page 1-26.**

Go To Diagnostics - Press button to go to Diagnostics. Refer to **"Diagnostics Menus" on page 1-34.**

Go To Data - Press button to go to the Data screen. Refer to **"Data Screens" on page 1-38.**

Conveyor Stop - Press button to stop the conveyor.

Conveyor Auto - Press button to start the conveyor. The conveyor defaults to Stop once the upper photocell is blocked.

Single Cycle - Press button to cycle the main ram once.


Cycle Stop - Press button to stop the cycle.

Tie Cycle - This acts as a manual tie override. Pressing this button takes the ram to the tie position.

Main Menu - Press button to go to the Main Menu.

Manual Mode - Press button to switch to the Manual Menu screen. Refer to **"Manual Menu Screens" on page 1-16.**

Manual Menu Screens



(Green or Gray Indicators) - The indicators on the left display the position of the ram as follows:

- Green indicates that the ram is in the indicated position.
- Gray indicates the ram is not in the indicated position.

Main Menu - Press this button to go to the Main Menu screen.

Tie Cycle - Acts as a manual tie override. Press this button to take the ram to the tie position.

Conveyor Manual On - Press this button to manually start the conveyor.


Conveyor Stop - Press this button to manually stop the conveyor.

Ram Extended - Press this button to manually extend the main ram.

Ram Retract - Press this button to manually retract the main ram.

Go To manual Tie - Press this button to go to the next Manual Menu screen (see next page), where you can manually control the tying process.

Manual Menu Screen - 2



(Green or Gray Indicators) - The indicators on the left display the position of the ram as follows:

- Green indicates that the ram is in the indicated position.
- Gray indicates the ram is not in the indicated position.

Go To Tier Pressure Setting Restricted Access - You must be logged in as "supervisor" to access. It takes you to Manual Menu Screen 3.

Manual Ram - Takes you back to Manual Menu Screen 1.

Needles In - Extends the inserter needles.

Needles Out - Retracts the inserter needles.


Twister In - Extends the twister head.

Twister Out - Retracts the twister head.

Twister Cut Position - Pressing this button rotates the wire twisters into the cut position to cut the bale wires.

Twist - Pressing this button manually twists the bale wires together a preset number of times.

Manual Menu Screen - 3



Return to Manual Tier - Takes you back to Manual Menu Screen 2.

Pressure Test On/Off - When "On", it allows you to bypass limits for the pressure setting in order to set release.

Tensioner Release - Releases pressure on the tensioner to allow for bale ejection and expansion.

Tensioner Hold Retracts Ram - Retracts the ram while the tensioner maintains pressure.

Slow On/Slow Off - When "On", it slows the operations of the baler.

Warning: Controls on This Screen Bypass Limits for Pressure Setting - Indicator screen.

Needles In - Extends the inserter needles.

Needles Out - Retracts the inserter needles.


Twister In - Extends the twister head.

Twister Out - Retracts the twister head.

Twister Cut Position - Pressing this button rotates the wire twisters into the cut position to cut the bale wires.

Twist - Pressing this button manually twists the bale wires together a preset number of times.

Fault Screen




This is a fault screen indicating that the machine has encountered a problem and operation cannot continue until the fault is corrected. Scroll through the faults using the up and down arrows.

The date and time of the fault are recorded here as well.

Press the "Reset" button to clear all listed faults.

Refer to the **"Fault List" on page 1-21** for a complete listing of possible faults.

Major Fault Screen



This screen indicates a fault condition exists. Automatic movement of the baler was stopped because it was not able to complete a function. For example, the ram could not reach the extend position proximity switch, due to too much material in the charge box.

- Press "Ack All" (acknowledge all) on the alarm banner.
- Press "Reset" on the fault list screen.
- Place the machine in Manual and correct the problem area.
- Then return all parts of the baler to their start position and return the baler to Automatic.

Fault List

The following faults will stop the baler motor.


The fault must be cleared and the motor restarted to continue operation.

- 1) An E-Stop is pressed or interlocked cover or door is open.
- 2) Suction valve is closed.
- 3) Main motor overload tripped.
- 4) Oil cooler overload tripped.
- 5) Low oil level.
- 6) High oil temperature.
 - Check the fan motor starter, output fuse, and auxiliary contact.
 - Check the main motor starter, output fuse, and auxiliary contact.

The following faults will stop automatic movement of the baler ram or tie system. The fault must be cleared and all parts of the baler returned to their starting position before automatic operation can continue.

- 1) Twister could not find the home position.
- 2) Ram cannot retract. Needles are not retracted.
- 3) Twister cannot extend. Needles are not retracted.
- 4) Needles cannot extend. Twister is not retracted.
- 5) Needles cannot extend. Ram is not at the tie position.
- 6) False cycle. Too many cycles without change in the photoeye.
- 7) Wire did not cut.
- 8) Ram jammed. Ram could not reach extend proximity switch.
 - Check photoeyes. Upper eye is blocked, lower eye is clear.
- 9) Ram could not retract or rear proximity switch failure.
- 10) Extend proximity switch failure.
- 11) Bale length proximity counter failure. No change in counter.
- 12) Needles could not extend or Needles Extended Limit Switch failure.
- 13) Needles could not retract or Needles Retract Limit Switch failure.
- 14) Twister Head could not reach home position proximity switch.
- 15) Tie system out of position.
- 16) Unloading valve failure.

General Setup Screens



Auto Mode Is Active - Indicator screen.

Twist Forward Counts - Press the number box (##) to display a numeric keypad for you to select the number of times the bale wires are twisted together.

To General Setup Screen 2 - Press this button to go to the next General Setup screen.

Go To Main Menu - Press this button to go to the Main Menu screen.

Go To Auto Screen - Press this button to go to the Auto Menu screen.

General Setup Screen 2


| | | |
|---------------------------------|------------------------|------|
| GENERAL SETUP NEXT SCREEN | AUTO MODE IS ACTIVE | BACK |
|---------------------------------|------------------------|------|

| | |
|--------------------|------|
| FALSE CYCLE COUNTS | ## |
| BALE TENSION | AUTO |

False Cycle Counts - Press the number box (##) to display a numeric keypad. Select the number of counts the baler will cycle with the upper photocell blocked. Gives fault.

Bale Tension - Can be set for "auto" (always recommended) or set to be "off".

General Setup Screen 3



Heat Exchanger - Pressing this button switches the heat exchanger (oil cooler) to the "Auto" mode. It is recommended to keep this on "Auto" during operation, not "Off".


General Setup Screen 4

| | | |
|--|------------------------|------|
| RETURN TO 1ST GENERAL SETUP SCREEN | AUTO MODE IS ACTIVE | BACK |
| MOTOR STOPS WHEN NOT BALING | | |
| IDLE TIME TO MOTOR STOP MINUTES | | |
| | | OFF |
| | | # |

Motor Stops When Not Baling - Pressing this button switches to the "On" setting, which programs the baler to stop after a set length of idle time.

Idle Time To Motor Stop Minutes - Pressing this button displays a numeric keypad which allows you to choose the length of idle time (in minutes) before the motor(s) automatically shut down.

Grade Setup Screens



Select Bale Recipe - You must login as the operator to change the Bale Recipe.

To Grade Setup Screen - You must login as a Supervisor to go to the next Grade Setup screen.

Go To Main Menu - Press this button to go to the Main Menu screen.

Go To Auto Screen - Press this button to go to the Auto Menu screen.

Grade Setup Screen 2

| | | |
|---------------------|------------------------------------|------|
| NEXT | SETUP GRADE RECIPE ## | BACK |
| AUTO MODE IS ACTIVE | | |
| ## | BALE LENGTH COUNTS | |
| #### | BALE TENSIONER RELEASE PRESSURE | |
| #### | BALE TENSIONER HOLD PRESSURE | |

Bale Length Counts - Displays the number of counts by the wheel counter.

Bale Tensioner Release Pressure - This is the set pressure at which point the tensioner releases the pressure on the bale.

Bale Tensioner Hold Pressure - This is the set pressure at which point the tensioner stops tensioning and holds until the set release pressure is reached.

Grade Setup Screen 3


| | | |
|---------------------|-------------------------------------|------|
| NEXT | SETUP GRADE RECIPE ## | BACK |
| AUTO MODE IS ACTIVE | | |
| #.# | BALE TENSIONER RELEASE TIME | |
| #.# | TIE CYCLE TENSIONER RELEASE TIME | |
| #.# | RAM CYCLE EYE DELAY | |

Bale Tensioner Release Time - Press the number box to display a numeric keypad that allows you to choose the amount of time (to one-tenth of a second) the bale tensioner releases pressure to allow for bale ejection and expansion.

Tie Cycle Tensioner Release Time - Time (to one-tenth of a second) additional to the bale tensioner release time which pressure is released to allow for the bale to be tied.

Ram Cycle Eye Delay - Time that the photocell is to be blocked before the ram activates. Can be set within one-tenth of a second.


Grade Setup Screen 4



The interface for Grade Setup Screen 4 consists of a top header bar and a main content area. The header bar has three blue rectangular buttons: 'NEXT' on the left, 'SETUP GRADE RECIPE ##' in the center (highlighted with a blue border), and 'BACK' on the right. Below the header, a yellow rectangular box displays the text 'AUTO MODE IS ACTIVE'. The main content area has a light gray background. On the left, the text 'RAM START POSITION:' is displayed. To the right of this text, three options are listed vertically: 'BACK' (highlighted with a white rectangular background), 'FORWARD', and 'TIE'. At the bottom of the screen, there are two circular buttons: a blue 'SCROLL' button on the left and a red 'ENTER' button on the right.

Ram Start Position - Push the "Scroll" button to select "Back", "Forward", or "Tie" for the starting position of the ram. Press "Enter" once the selected position is highlighted.

Grade Setup Screen 5



The interface for Grade Setup Screen 5 consists of a top header bar with three buttons: 'NEXT' on the left, 'SETUP GRADE RECIPE ##' in the center, and 'BACK' on the right. Below the header, a yellow status bar displays 'AUTO MODE IS ACTIVE'. The main area has a light gray background. On the left, the text 'RAM CYCLE POSITION:' is displayed. To its right, two options are listed: 'FORWARD' and 'TIE', with 'FORWARD' being highlighted by a white rectangular box. At the bottom, there are two circular buttons: a blue 'SCROLL' button on the left and a red 'ENTER' button on the right.

Ram Cycle Position - Push the "Scroll" button to select "Forward" or "Tie" for the position to which the ram extends. Press "Enter" once the selected position is highlighted.


Grade Setup Screen 6

The screen features a top navigation bar with three buttons: "NEXT" on the left, "SETUP GRADE RECIPE ##" in the center, and "BACK" on the right. Below this bar, a yellow status box displays "AUTO MODE IS ACTIVE". The main area shows "AUTO CYCLE EYE:" followed by a scrollable list of options: "OFF", "MID", "UPPER (OPTIONAL)", "MID OR KNIFE", and "MID AND KNIFE". At the bottom left are two circular buttons: a blue "SCROLL" button and a red "ENTER" button.

Press the "Scroll" button to select the photocell (in the Auto Cycle Eye list) that activates the main ram to begin auto-cycling. Press "Enter" once the selected photocell is highlighted. This setting is changed according to baling material size. For example, when baling larger material such as corrugated cardboard, select the "Upper" photocell. When baling smaller material such as office paper, select either one or both of the lower photocells, depending on material density.

Note: Not all auto-tie baler models contain all of the photocell options shown above.

Grade Setup Screen 7



The interface for Grade Setup Screen 7 consists of a top header bar with three buttons: 'NEXT' on the left, 'SETUP GRADE RECIPE ##' in the center, and 'BACK' on the right. Below the header, the main area is titled 'CONVEYOR RUNS ON:'. Under this title, there is a list of options: 'OFF', 'LOWER', 'UPPER', 'EITHER', and 'BOTH', followed by the text 'WHEN BALER IS IN AUTO'. To the right of this list is a label 'CONVEYOR FEED EYE DELAY' above a numeric keypad represented by a blue box containing '#.#'. At the bottom left, there are two circular buttons: a blue one labeled 'SCROLL' and a red one labeled 'ENTER'. At the bottom right, there is a yellow rectangular box containing the text 'AUTO MODE IS ACTIVE'.

Conveyor Runs On - Press the blue scroll button to select which photocell stops the conveyor for the duration of the ram cycle. Press "Enter" once the selected photocell is highlighted.

Conveyor Feed Eye Delay - Press this button to display a numeric keypad to select the length of time, in seconds, the photocell is blocked before the conveyor stops.


Grade Setup Screen 8

The interface for Grade Setup Screen 8 consists of a top navigation bar with three blue buttons: "RETURN TO 1ST SCREEN", "SETUP GRADE RECIPE ##" (highlighted with a blue border), and "BACK". Below this is a large grey area. At the top of this area is a yellow box containing the text "AUTO MODE IS ACTIVE". Below the yellow box are two settings. The first setting is "CONVEYOR STOPS WHEN RAM MOVES:" followed by a blue "CHANGE" button and a red circular button labeled "OFF". The second setting is "PARTIAL STROKE MODE:" followed by a blue "CHANGE" button and a green circular button labeled "ON".

Conveyor Stops When Ram Moves - This setting controls the conveyor when the ram is in motion. Press "Change" to choose this function to be "Off" or "On".

Partial Stroke Mode - This option is only available on shear model auto-ties. When "On", it allows the baler to calculate whether or not a partial ram cycle is needed to create an average, consistent bale length.

Diagnostics Menus



Note: The Diagnostics Menu and subsequent screens may only be accessible by Marathon personnel. In the event that you need to access this, please call our service department at 1-800-633-8974 and proper instructions will be given accordingly.

Diagnostics Menu 2

| | | |
|-------------------------------|---------------------|------------------------------------|
| TO DIAGNOSTICS SCREEN 3 | AUTO MODE IS ACTIVE | BACK TO DIAGNOSTICS SCREEN 1 |
|-------------------------------|---------------------|------------------------------------|

DUAL 30 HP POWER UNIT

Diagnostics Menu 3

| | | |
|--------------------------------------|---------------------|------------------------------------|
| RETURN TO DIAGNOSTICS SCREEN 1 | AUTO MODE IS ACTIVE | BACK TO DIAGNOSTICS SCREEN 2 |
|--------------------------------------|---------------------|------------------------------------|

MAX SYSTEM PRESSURE

REGEN SETPOINT

MOTOR FULL LOAD AMPS

Input/Output Status Screens

| GoTo INPUT/ OUTPUT SCREEN 2 | INPUT OUTPUT STATUS | | GoTo DIAGNOSTICS |
|-----------------------------------|---------------------|--------------------------|---------------------|
| | AUTO MODE IS ACTIVE | | |
| I:0/0 STOP | | I:0/7 | |
| I:0/1 | | I:0/8 PROX RET POS | |
| I:0/3 PROX TIE POS | | I:0/9 NEEDLE IN LS | |
| I:0/4 | | I:0/10 NEEDLES RET LS | |
| I:0/5 PROX EXT POS | | I:0/11 | |
| I:0/6 | | | |

Input/Output Status Screen 2

| GoTo INPUT/ OUTPUT SCREEN 3 | INPUT OUTPUT STATUS | | GoTo INPUT/ OUTPUT SCREEN 1 |
|-----------------------------------|------------------------------|------------------------------|-----------------------------------|
| | AUTO MODE IS ACTIVE | | |
| I:1/0 TWISTER HOME PROX | I:1/6 FAN AUXILLERY | I:1/12 | |
| I:1/1 TWISTER COUNTER PROX | I:1/7 MOTOR OVERLOAD | I:1/13 SUCTION VALVE PROX | |
| I:1/2 TWISTER HEAD HOME PROX | I:1/8 FAN OVERLOAD | I:1/14 LOWER PHOTOEYE | |
| I:1/3 | I:1/9 OIL TEMP FAN ON | I:1/15 UPPER PHOTOEYE | |
| I:1/4 BALE LENGTH PROX | I:1/10 OIL TEMP SHUTDOWN | | |
| I:1/5 M1 AUXILLERY | I:1/11 OIL LEVEL SHUTDOWN | | |

The Input/Output screens coincide with the PLC and electrical schematic to show which components have power to them by illuminating green. If there is no power to the specific input/output, the box remains gray.

Input/Output Status Screen 3


| GoTo INPUT/ OUTPUT SCREEN 4 | | INPUT OUTPUT STATUS | | GoTo INPUT/ OUTPUT SCREEN 2 | |
|-----------------------------------|-------|---------------------|--------|-----------------------------------|--|
| | | AUTO MODE IS ACTIVE | | | |
| | 0:0/0 | | 0:0/6 | | |
| | 0:0/1 | | 0:0/7 | | |
| | 0:0/2 | | 0:0/8 | | |
| | 0:0/3 | | 0:0/9 | | |
| | 0:0/4 | | 0:0/10 | | |
| | 0:0/5 | | 0:0/11 | | |

Input/Output Status Screen 4

| GoTo INPUT/ OUTPUT SCREEN 1 | INPUT OUTPUT STATUS | | GoTo INPUT/ OUTPUT SCREEN 3 |
|-----------------------------------|---------------------|--------------------|-----------------------------------|
| | AUTO MODE IS ACTIVE | | |
| 0:2/0 | | 0:2/6 | 0:2/12 |
| 0:2/1 | | 0:2/7 | 0:2/13 |
| 0:2/2 | | 0:2/8 | 0:2/14 |
| 0:2/3 | | 0:2/9 ALARM | 0:2/15 |
| 0:2/4 | | 0:2/10 TIE MODE | |
| 0:2/5 | | 0:2/11 RUN MODE | |

The Input/Output screens coincide with the PLC and electrical schematic to show which components have power to them by illuminating green. If there is no power to the specific input/output, the box remains gray.

Data Screens



Bale Counts - Indicates number of bales made since the last reset.

Bale Count Reset - Press to reset the bale counter.


To Data Screen 2 - Takes you to the next Data screen.

Go To Main Menu - Takes you to the Main Menu.

Go To Config. Screen - Press this button to take you to the Configuration screen, which should only be used to change the time and date for date stamping and fault analysis. Other functions in this mode are to be used by trained personnel only.

Go To Auto Screen - Takes you to the Auto Menu.

Data Screen 2



Bale Counts Life Time - Indicates the number of total bales made during the life of baler.

Motor Hours - Indicates the total number of hours the motor(s) have been in operation.

Data Screen 3

| | | |
|---|---------|----------------------------|
| NEXT DATA SCREEN | DATA | PREVIOUS DATA SCREEN |
| MM/DD/YY 1H:MM:SS PM 1H:MM:SS PM 12 CIR PUMP NOT ON WHEN MAIN MOTOR STARTED. | | ▲ |
| ▶ □ | | ▼ |
| Clear List | Ack All | ← |

This is a Data screen listing the last 10 faults the baler has encountered. Scroll through the faults using the up and down arrows.

The date and time of the fault are recorded here as well.

Press the "Clear List" button to clear all listed faults.

Refer to the **"Fault List" on page 1-21** for a complete listing of possible faults.

Data Screen 4

| | | | |
|---------------------|-------------|--------------------|----------------------------|
| TO DATA SCREEN 1 | DATA | | PREVIOUS DATA SCREEN |
| AUTO MODE IS ACTIVE | | | |
| <u>DATE</u> | <u>TIME</u> | <u>LAMINATIONS</u> | |
| ##/## | ##:0# | ### | PAGE UP |
| ##/## | ##:0# | ### | |
| ##/## | ##:0# | ### | |
| ##/## | ##:0# | ### | PAGE DOWN |
| ##/## | ##:0# | ### | |


This screen (and subsequent screens) stores the statistics for the last 50 bales made. Scroll through using the "Page Up" and "Page Down" buttons.

Bale Length Counter


Setting Bale Length Counter

- 1) Bale length counter is set in **"Grade Setup Screens Screens"** on page 1-26.



End View of Bale Length Counter Wheel



Side View of Bale Length Counter Wheel



This Proximity Switch signals the P.L.C. as each wheel tooth passes the switch.




Bale Plug Instructions

To begin baling process, it is necessary to build a plug or barrier in the extrusion chamber, to form a compaction wall. The bale plug process is as follows:


- 1) Lock-Out and Tag-Out per **"Lock-Out & Tag-Out Instructions" on page 2-2.**
- 2) Insert 2" x 2" boards through tie slots. (see drawing below)
- 3) Manually tie wire* to post. (see drawing)
 - Twist and tie wire behind post. (see drawing)
- *See the next two pages for wire box installation instructions and diagrams.
- 4) Perform machine start up per instructions.
- 5) Press "Manual tie" cycle to tie wires.
- 6) Remove scrap wire tied to post.
- 7) Load feed chamber with material to create first bale.
- 8) Press "START CYCLE" button. The ram will move forward and compact material and return to its retract position.
- 9) Continue to cycle ram until 2 x 2"s break.
- 10) Press tie cycle to tie off bale.
- 11) Follow the **"Lock-Out & Tag-Out Instructions" on page 2-2.**
- 12) Remove 2 x 2's.
- 13) Start normal baling processing.

Bale Plug Instructions (Continued)




Wire Box Loading

Typical Wire Box Installation




Load individual wire boxes in each compartment (labeled # 1 - 5 in diagram) on each side of the baler.



Optional Wire Installation

Optional 1000#
Coil Stump Feed System -
Wire feeds into baler in a
similar manner.



General Overview of the Auto-Tie Cycle

During tie cycle, the Inserter Needles travel across the width of the baler and capture the wires on the side opposite the tier. The needles then retract, capture the wires on the tier side and position the wires to be twisted, then cut.

The hydraulic Wire-Feeding Arms on the tier side of the baler lift the wires as the Inserter Needles travel across the baler and lower the wires as the needles retract. This ensures that the wire on the tier side is captured upon return of the needles.

The Spring Feeder Arms on the side opposite the wire-tier must be manually adjusted if the Inserter Needles miss the wires on that side. The instructions BELOW AND on the following pages describe wire-routing for each side, along with Wire-Tensioner adjustment and Spring-Feeder adjustment.

Prior to routing wires in the auto-tie baler, the compaction ram must be moved to the tie position using the baler controls.

Wire Routing and Installation

(see **“Wire Box Loading” on page 1-45**)

The wires must be properly routed on each side of the baler from the five installed wire boxes (or optional stump feed system). First cut the tape binding the wire spool together inside the box. Then pull the wire through the wire nozzles, wire-tensioner, and wire feeder arms (shown **on page 1-47**).

Adjusting the Wire-Tensioner

(see **“Wire Installation & Adjustment” on page 1-47**)

The Wire-Tensioner can be adjusted to put more or less tension in the wire by loosening the Jam Nut and turning the Adjustment Bolt. The bolt can be tightened for more tension in the wire and loosened for less tension.


To load the wire in the wire-tensioner, first loosen the Jam Nut, then turn the adjustment bolt counter-clockwise to raise the center bank of rollers to allow just enough room to insert the wire. Insert the wire behind the Wire Shields, on top of the 2 lower rollers and under the top adjusting roller.

Turn the Adjustment Bolt clockwise to lower the center bank of rollers until all rollers contact the wire and then turn one more complete turn. Tighten the Jam Nut.


Note: The correct wire tension depends on the wire gauge, the tensile strength of the wire, the amount of oil on the wire, if any, and other factors. More or less tension may be required as bale density increases. If there is too much slack in the wire, the tensioner needs to be tightened. If the wire isn't being pulled from one side or if the wire breaks, the tensioner needs to be loosened.

Wire Installation & Adjustment


Wire-Tier Side



Enlarged Top View




Enlarged View



Wire Tier Side Elevation View

Wire Installation & Adjustment Opposite Wire-Tier Side


As the Inserter Needles traverse to the opposite side of the baler, the wires **MUST** travel up and over the Needle Heads and drop down into the gap behind. When the needles retract, the wire is forced against the Needle Head Roller and brought back to the tier side of the baler.



Spring Feeder Adjustment - Opposite Wire-Tier Side


Note: Spring feeder arm positions have been factory set and should ensure correct position for needles to capture wire. However, in the event that the needle heads do not capture the wire, the spring feeders can be adjusted to raise OR lower the roller arms for correct alignment.

The Spring Feeders are located on the side of the baler opposite the wire tier and hold the bale tie wire at the correct height for the Inserter Needles to pass underneath the wire. If the wire is too low, the needles will pass over the wire and will not capture it. The Arms need to be raised by first loosening the Jam Nut, then turning the adjustment bolt counterclockwise. The Jam Nut must be retightened once the Arms are in the correct position. If the wire is too high, it will not be forced into the gap behind the needle head and the needles will not capture it. In this case, The arms need to be lowered by turning the Adjustment Bolt clockwise.



Spring Feeder - Front View

View has been rotated 90° from side view.




Spring Feeder Side View

Wire (inserts on top of 2 lower rollers & under top adjusting roller behind wire shields after passing through the wire nozzle).

Insertor Needle Risers

The Insertor Needle Risers serve as ramps to raise the needles as they pass through the width of the baler to the side opposite the wire tier. To ensure that the needles are in the correct position to capture the wire, the risers can be adjusted by loosening the two bolts, moving the chamfered wear pads up or down, and then retightening the bolts.



**Insertor Needle
Riser - Side View**


Wire Installation - Initial Wire Connection

Once all of the wires have been inserted through the wire nozzle, wire tensioner, and the roller arms on both sides of the baler (hydraulic feeder arms on the tier side and spring feeder arms on the opposite side), the wire must be fed across the baler from the side opposite the wire tier to the tier side. Both wires must be twisted together with wire pliers at least 10 times to ensure a good wire knot.


The baler is now ready to begin or resume baling.

Decal Diagram

Refer to **“Decal Description” on page 1-52** for descriptions.




Front View



Rear View

Decal Diagram (Continued)

Refer to **“Decal Description” on page 1-52** for descriptions.



Decal Description

Warning Decal Requirements

When your baler leaves the factory, several Warning Decals are installed for everyone's protection. These labels are subject to wear and abuse due to the nature of baling operation. All DECALS MUST BE MAINTAINED. Replacement decals may be purchased through your distributor or by contacting the Service Department listed in the Maintenance Section.

Images of decals are shown on the next page.

| Part # | Ref # | Description |
|---------|-------|--|
| 06-2751 | 1 | Marathon Compaction & Recycling Solutions 6"X10" |
| 06-0249 | 3 | Danger: High Voltage, Crushing, Pressurized Fluid |
| 06-0475 | 4 | Caution: Crushing Hazard - Keep clear while in operation |
| 06-0121 | 5 | Caution: Federal reg prohibits operation under 18. |
| 06-0129 | 6 | Caution: Periodic maintenance is required... |
| 06-0038 | 7 | Warning: Do not remove access cover |
| 06-0120 | 8 | Danger: Disconnect and lock-out power before... |
| 06-0133 | 9 | Warning: Fall Hazard - Do not climb on equipment |
| 06-3044 | 10 | Danger: Volts _____ (insert appropriate decal) |
| 06-0250 | 11 | Danger: Lock out and tag out power before... |
| 06-0041 | 12 | Warning: Crushing Hazard - Machine starts automatically |
| 06-0039 | 13 | Danger: Crushing/Shearing Hazard - Do Not Enter |
| 06-1839 | 14 | American Flag |
| 06-0097 | 15 | Serial Number Plate Non UL |
| 06-0003 | 16 | Patent Pending |
| 06-3053 | 17 | Danger Volts _____ (2" X 4") |
| 06-3049 | 18 | TIEger Auto-Tie Balers Logo |
| 06-3123 | 19 | Danger: Confined Space |
| 06-2684 | 20 | 208 (Insert on 06-3044 as required for voltage) |
| 06-2686 | 21 | 230 (Insert on 06-3044 as required for voltage) |
| 06-2690 | 22 | 460 (Insert on 06-3044 as required for voltage) |

Decal Images

06-0003



06-0038



06-0039



06-0041



06-0120



06-0121



06-0129



06-0133



06-0249



06-0250




06-0475




06-1839




06-2684



06-2686



06-2690



06-0097



06-2751



06-3044



06-3049



06-3053




06-3123



2 - MAINTENANCE

Lock-Out & Tag-Out Instructions




Before entering any part of the baler, be sure that all sources of energy have been shut off, all potential hazards have been eliminated, and baler is locked-out and tagged-out in accordance with OSHA and ANSI requirements.

If ram is pressing against a load, move ram rearward before shutting baler down. Specific lock-out and tag-out instructions may vary from company to company (i.e. multiple locks may be required, or other machinery may need to be locked-out and tagged-out). The following instructions are provided as minimum guidelines.

Instructions:

- 1) Move main disconnect lever to OFF position.
- 2) Padlock disconnect lever with a keyed padlock and take key with you.
- 3) Along with padlock, place an appropriate, highly visible, warning tag on disconnect lever. Tag should provide a warning such as: "**Danger:** Do not operate equipment. Person working on equipment. **Warning:** Do not energize without permission of _____."
- 4) After locking and tagging baler, try to start and operate baler (as outlined in Operating Instructions) to make sure lock-out and tag-out is effective. If lock-out and tag-out is effective, remove key from key switch and take with you.



Electrical: The panel box contains high voltage components. Only authorized service personnel should be allowed inside box. Authorized service personnel should be allowed inside box only after baler has been locked-out and tagged-out.

Hydraulic: Stored hydraulic energy must be removed from baler hydraulic circuit for complete lock-out and tag-out. Make sure that all personnel are clear of compaction and ejection areas. To remove pressure from system, make sure the ram is not pressing against a load. Manually depress poppet valve pin located in center of each poppet valve on main manifold and hold pin for a couple of seconds. See power unit layouts in this section of manual for poppet and manifold location.

Marathon Equipment's Service Department

Business Hours:

8am - 5pm

Monday - Friday

(**C**entral **S**tandard **T**ime)

For Parts & Warranty please call:

1-800-528-5308

For Technical Assistance please call:

1-877-258-1105

Periodic Maintenance

Danger: Only authorized and trained personnel should perform the following procedures. Lock-Out and Tag-Out the baler per as specified in **"Lock-Out & Tag-Out Instructions" on page 2-2.**

After Start-Up

- 1) Replace return line filter after the start-up technician has completed the initial start-up of the machine.

Daily (Operator)

- 1) Open wire twister cabinet and check for material build-up in bottom of cabinet. Clean out any material found in twister or its enclosure.
- 2) Check for material build-up behind the compaction ram.
- 3) Check for material build-up under bale length counter cover.
- 4) Check oil level and temperature in hydraulic reservoir. Maintain oil level above 3/4 full in sight gauge. Temperature should be below 160° F.
- 5) Check all remote emergency stop locations. Make sure each emergency stop button is not obstructed, damaged, or depressed.
- 6) Make sure operator area and access door are free from hazards that could cause a slip, trip, or fall.
- 7) Make sure that there is an adequate supply of wire on all wire reels.
- 8) Inspect for hydraulic system leak.

Weekly (Operator)

- 1) Check all limit switches to ensure free movement.
- 2) Clean photocell heads and reflectors.
- 3) Check function of all emergency stop buttons and interlock switches.
- 4) Check return line filter indicator located on top of power unit. See power unit drawings located later in this section. If indicator is in red portion of scale, discontinue use of baler and call for service.

Periodic Maintenance (Continued)

Monthly (Service Personnel)

- 1) Check all hoses for chaffing, rubbing, or other deterioration and damage.
- 2) Inspect breather cap on hydraulic reservoir. Clean or replace as necessary.
- 3) Check cylinder pins and make sure they are secure.
- 4) Check holddown bar clearance above ram. Clearance should be 1/32" or less. Adjust as necessary. See procedure later in this section of the manual.
- 5) After the first 160 hours of operation, return line filter needs to be replaced. After this replacement, return line filter maintenance/replacement will be extended to every 600-1000 hours of operation.
- 6) Inspect baler floor plate and liners for excessive wear.
- 7) Lubricate access door hinges and extrusion chamber hinges.
- 8) Apply a thin covering of lubricant to all tier gears and inserter chain.

Recommended lubricants are:

- CRC Dry Moly Lubricant (high solids molybdenum disulfide), 16 ounce spray can. Available from Grainger #2F138.
- Slip Plate Graphite Dry Film Lubricant, 16 ounce spray can. Available from Grainger #2F138.

Semi-Annually (Service Personnel)

- 1) Send oil sample out for evaluation.
- 2) Check baler structure for any signs of problems (such as cracked welds, bending, etc.).
- 3) Inspect cylinder rod of compression ram cylinders for nicks and abrasions. Check main cylinder rod seals for damage. Inspect cylinder pins for movement or missing cotter pins.

Annually (2000 hours of operation)

- 1) Send oil sample out for evaluation. If contaminated, replace hydraulic fluid of the entire system. The hydraulic tank should be cleaned inside with a nonflammable solvent and thoroughly dried before replacing oil.
- 2) Lubricate electric motor bearings as recommended by manufacturer.

Periodic Maintenance (Continued)


Annually

- 1) Change hydraulic fluid in entire system. If existing oil is reused, it should be tested by a laboratory to ensure it meets necessary specifications. Additives can be added to bring oil back to standards. Before returning oil to tank, it should be filtered through a minimum 6 micron filter. Hydraulic tank should be cleaned inside with a nonflammable solvent and thoroughly dried before replacing oil.
- 2) Lubricate electric motor bearings as recommended by manufacturer.
- 3) Filter maintenance:
 - a) Hydraulic suction filters should be cleaned at yearly intervals.
 - b) Filters may be removed from unit by disconnecting the union on the suction side of pump (circulating pump for oil cooler), or by removing four bolts that retain suction flange to main pump, and lifting the filter from reservoir.
 - c) Care should be exercised in cleaning the filter to ensure that the element is not torn. Clean the filter with a soft brush and standard industrial solvent.
 - d) Replace filter after cleaning. Tighten union, or bolts, securely. Pump noise and a "crackle" sound is most often caused by air entering the pump suction line. Tightening suction fittings will usually eliminate problem.

Recommended Oils

- Union-UNAX-46, UNAX-AW46
- Gulf-Harmony 47, Harmony 48-AW
- Exxon-Teresstic 46, NUTO 46
- Texaco-Rando 46
- Chevron-AW 46
- Shell-Turbo 46, Tellus 46
- Citgo-Pacemaker 46, Tellus-AW46
- Conoco-Super Hydraulic Oil 46
- Quaker State-Dextron II (ATF) Automatic Transmission Fluid
- Amoco-Rycon MV Cold Weather Fluid

Power Unit Drawing 30 HP



Power Unit Reference Numbers 30 HP

| Part # | Ref. # | Description | Qty. |
|---------|--------|--|------|
| 02-0021 | 1 | COUPLING 1/4 NPT | 1 |
| 02-0040 | 2 | ADAPTER 3/8 NPTF X 1/2 NPTM | 1 |
| 02-0048 | 3 | NIPPLE 3/4 NPT | 2 |
| 02-0132 | 4 | ADAPTER 1/2 NPTF X 3/4 NPTM | 1 |
| 02-0214 | 5 | VALVE RELIEF 20 GPM CART PILOT | 1 |
| 02-0215 | 6 | GAUGE SIGHT LEVEL 5 INCH | 2 |
| 02-0254 | 7 | PLUG 2 NPT SQ HD | 2 |
| 02-0300 | 8 | VALVE RELIEF 20 GPM CART PILOT | 1 |
| 02-0310 | 9 | TEE 3/4 NPTF | 1 |
| 02-0316 | 10 | PLUG 3/4 NPT | 1 |
| 02-0332 | 11 | HOSE END 3/8 WB X 3/8 NPTM | 1 |
| 02-0565 | 12 | FLANGE C61 1 1/4 SPLIT | 4 |
| 02-0606 | 13 | TUBING END 3/8 X 6 ORM 90 | 2 |
| 02-0612 | 14 | CLAMP TUBE 3/8 WELD | 2 |
| 02-0634 | 15 | FLANGE C61 1 #12 O-RING | 1 |
| 02-0668 | 16 | FILTER SUCTION 3 NPTF 100 GPMSEC-100-3 | 1 |
| 02-0697 | 17 | ELL 12 ORM X 12 JICM | 1 |
| 02-0698 | 18 | HOSE END 3/4 WB X 12 JICF | 2 |
| 02-0805 | 19 | COUPLING 2 SCH 40 | 2 |
| 02-0822 | 20 | TEE 12 JICM X 12 ORM BRANCH | 1 |
| 02-0823 | 21 | CLEAN OUT COVER 14 | 2 |
| 02-0824 | 22 | CLEAN OUT COVER MNTG BRKT REMOVABLE | 2 |
| 02-0863 | 23 | OIL COOLER AOCH-20 | 1 |
| 02-0872 | 24 | FLANGE C61 4 WELD 500 PSI | 1 |
| 02-0878 | 25 | FLANGE C61 1 SPLIT W/BOLTS | 2 |
| 02-0879 | 26 | HOSE END 1 WB X 1 F61 SPT 90 | 1 |
| 02-0883 | 27 | ELL 1 1/4 WELDF 90 SCH 160 | 1 |
| 02-0908 | 28 | HOSE END 1 WB X 1 F61 SPT | 1 |
| 02-0932 | 29 | HUB COUPLING 1 1/4-5/16 X 1 7/8-1/2 | 1 |
| 02-1028 | 30 | NIPPLE 3 NPT SCH 40 | 1 |
| 02-1062 | 31 | FLANGE C61 1 1/4 WELD COMP W61-20-20 | 1 |
| 02-1088 | 32 | HOSE END 1 1/4 WB X 1 1/4 F61SPT 3000 | 1 |
| 02-1098 | 33 | HOSE END 1 1/4 WB X 1 1/4 F6190 5000 | 2 |
| 02-2258 | 34 | CLAMP FOR 1 1/2 ID HOSE BARB FITTING | 1 |
| 02-3427 | 35 | COUPLING 4 SCH 40 FEMALE NPT THREAD | 1 |
| 02-3780 | 36 | HOSE END 3/8 2WB X 6 JICF SWV | 1 |


Power Unit Reference Numbers 30 HP (Continued)

| Part # | Ref. # | Description | Qty. |
|---------|--------|--|------|
| 02-4043 | 37 | ADAPTER PUMP/MTR SAE C 2B X 286TC X 7.88 | 1 |
| 02-4154 | 38 | HOSE END 3/4 WB X 12JICF 90 DAYCO#HY12-12FJ | 2 |
| 02-4155 | 39 | ELL 3/4 NPTM X 12 JICM 90 KRJOHNSON 2501-12- | 1 |
| 02-4253 | 40 | FILTER BREATHER BAYONET FLANGE 2 INCH | 1 |
| 02-4254 | 41 | FILTER BREATHER BASKET 2 INCH | 1 |
| 02-4324 | 42 | FILTER RETURN 12 ORM 6 MICRONTANK TOP VICKER | 1 |
| 02-4328 | 43 | FILTER BREATHER BAYONET ADAPTER F/ 02-3229 | 1 |
| 02-4330 | 44 | FILTER BREATHER SPIN ON VICKERS V0211B1R03 | 1 |
| 02-4331 | 45 | CAP 2 NPT SCH 40 | 1 |
| 02-4340 | 46 | ADAPTER 1/2 NPTM X 12 JICM | 1 |
| 02-4343 | 47 | FILTER INDICATOR GAUGE 1/8 NPTM COLOR CODED | 1 |
| 02-4404 | 48 | MANIFOLD DUAL D08 REGEN 75 GPM | 1 |
| 02-4405 | 49 | VALVE 4-WAY 08 T 3-POS EXT P&D HI-FLOW | 1 |
| 02-4406 | 50 | VALVE 4-WAY 08 A TO T 3-POS EXT P & D HI-FLO | 1 |
| 02-4407 | 51 | PUMP VANE 53 18 12 VICKERS VMQ | 1 |
| 02-4409 | 52 | UNLOADING VALVE 1 1/4 W/ SOLENOID VENT | 1 |
| 02-4410 | 53 | VALVE CHECK 1 1/4 CODE 61 FLANGE 75 PSI CRAC | 1 |
| 02-4411 | 54 | ELL 6 ORM X 6 JICM | 1 |
| 02-4426 | 55 | VALVE BUTTERFLY 4 WAFFER SUCTION | 1 |
| 02-4427 | 56 | FLANGE ANSI 4 NPTF | 2 |
| 03-1179 | 57 | MOTOR 30 HP 1760 208-230/460V286TC TEFC SP | 1 |
| 03-3689 | 58 | SWITCH LEVEL PLUG ADAPTER 1 1/4 | 1 |
| 05-0015 | 59 | NUT 3/8-16 UNC HEX SELF-LOCKING | 4 |
| 05-0052 | 60 | WASHER 1/2 FLAT | 1 |
| 05-0061 | 61 | BOLT 1/2-13 X 1 1/4 HEX HD GR2 | 8 |
| 05-0064 | 62 | WASHER 1/2 LOCK | 4 |
| 05-0075 | 63 | NUT 1/2-13 HEX SELF-LOCKING | 11 |
| 05-0105 | 64 | NUT 5/16-18 HEX SELF-LOCKING | 2 |
| 05-0148 | 65 | BOLT 1/2-13 X 1 | 7 |
| 05-0199 | 66 | BOLT 1/2-13 X 2 1/2 ALLEN HD | 12 |
| 05-0236 | 67 | BOLT, HEX, 3/4-10UNC X 5 1/2 | 4 |
| 05-0263 | 68 | NUT 3/4-10 HEX LOCKING | 4 |
| 05-0338 | 69 | BOLT 5/8 X 1 1/2 GR 2 HHCS ZINC | 2 |
| 05-0521 | 70 | WASHER 1/2 LOCK GRADE 8 HI-COLLAR80-0123 | 12 |
| 05-0549 | 71 | BOLT5/16-18 X 1 1/4 GRD 5 HEXHD` | 6 |
| 05-0561 | 72 | WASHER 5/8 LOCK | 2 |



Power Unit Reference Numbers 30 HP (Continued)

| Part # | Ref. # | Description | Qty. |
|---------|--------|---|------|
| 05-2301 | 73 | NUT 5/8-11 NC SLN | 4 |
| 05-3644 | 74 | BOLT 7/16-14 X 7 1/2 SOCKET HD GRADE 8 | 4 |
| 05-2001 | 75 | WASHER, LOCK, 5/16" | 4 |
| 06-0011 | 76 | DECAL MOTOR ROTATION 3/4 X 4 | 1 |
| 23-5425 | 77 | 1 1/4 X SCH80 X 4 PIPE SQ CUT | 1 |
| 26-9656 | 78 | 1/2 X SCH40 X 23 PIPE | 1 |
| 27-5256 | 79 | 7GA X 1-1/4 X 5 | 1 |
| 28-1367 | 80 | 1 1/4 X SCH40 X 23 PIPE | 1 |
| 28-1562 | 81 | 1/4 X SCH80 X 6 PIPE | 1 |
| 28-1869 | 82 | 7GA X 13 X 14-3/4 | 1 |
| 28-6058 | 83 | 2 1/2 X SCH40 X 24 PIPE | 1 |
| 28-6693 | 84 | 7GA X 3 X 20 | 1 |
| 28-6694 | 85 | 1/4 PL X 3 X 3 | 1 |
| 28-8762 | 86 | 4 X SCH40 X 6 PIPE | 1 |
| 28-8763 | 87 | 4 X SCH40 X 15 PIPE | 1 |
| 28-8953 | 88 | 7GA X 6-3/4 X 12 (1=2) | 1 |
| 28-8963 | 89 | 7GA X 14 X 28-1/4 | 1 |
| 99-0676 | 90 | WASHER 7/16 HI-COLLAR LOCKING | 4 |
| 99-6723 | 91 | ADAPTER 4 NPTM X 3 NPTF | 1 |
| 99-6929 | 92 | HOSE END 1 1/4 WB X 1 1/4 F61SPT 45 | 1 |
| 99-7009 | 93 | SWITCH OIL LEVEL & TEMP NC UPTL 008180F | 1 |
| 99-7152 | 94 | COUPLING 4 DRESSER 4 BOLT X 5LONG | 1 |
| 99-7235 | 95 | BOLT 5/8-11 X 4 1/2 NOT PLATED | 4 |
| 99-7783 | 96 | ADAPTER 3/4 NPTF X 2 NPTM SCH80 | 2 |
| 02-0880 | 97 | HOSE 1 WB 4000PSI | 4 |
| 02-0335 | 98 | HOSE 1 1/4 WIRE BRAID 5000 | 6 |
| 02-0333 | 99 | HOSE 3/8 WIRE BRAID (TWO) 2500 PSI | 2 |
| 02-3725 | 100 | TUBING 3/8 OD .083 WAL | 8 |
| 02-0327 | 101 | HOSE 3/4 2WB 3100 PSI | 5 |
| 02-1091 | 102 | HOSE 1 1/2 WB 5000PSI | 1 |

Power Unit Drawing - 2 X 30 HP Motors



Power Unit Drawing - 2 x 30 HP Motors (continued)



Power Unit Reference Numbers - 2 x 30 HP

| Part # | Ref.# | Description | Qty. |
|---------|-------|--|------|
| 02-0021 | 1 | COUPLING 1/4 NPT | 1 |
| 02-0025 | 2 | NIPPLE 3/8 NPT | 2 |
| 02-0029 | 3 | ELL 1/2 NPTM X 1/2 NPTF SWV 90 | 2 |
| 02-0030 | 4 | ADAPTER 3/4 NPTF X 1 1/4 NPTM | 1 |
| 02-0035 | 5 | TEE 1/2 NPTF | 2 |
| 02-0036 | 6 | NIPPLE 1/2 NPT | 2 |
| 02-0040 | 7 | ADAPTER 3/8 NPTF X 1/2 NPTM | 2 |
| 02-0044 | 8 | ELL 3/4 NPTM X 3/4 NPTF 90 | 3 |
| 02-0048 | 9 | NIPPLE 3/4 NPT | 4 |
| 02-0050 | 10 | FILTER SUCTION 1 13 GPM 100 MESH | 2 |
| 02-0124 | 11 | ADAPTER 3/8 NPTF X 3/4 NPTM | 2 |
| 02-0132 | 12 | ADAPTER 1/2 NPTF X 3/4 NPTM | 2 |
| 02-0157 | 13 | VALVE 4-WAY 05 O 2-POS | 2 |
| 02-0204 | 14 | CHECK VALVE 1/2 NPTF | 4 |
| 02-0214 | 15 | VALVE RELIEF 20 GPM CART PILOT | 2 |
| 02-0215 | 16 | GAUGE SIGHT LEVEL 5 INCH | 2 |
| 02-0238 | 17 | ELL 1 NPTM X 1 NPTF SCH 40 | 5 |
| 02-0239 | 18 | UNION 1 NPT | 2 |
| 02-0240 | 19 | NIPPLE 1 NPT CLOSE | 3 |
| 02-0254 | 20 | PLUG 2 NPT SQ HD | 2 |
| 02-0264 | 21 | SUBPLATE WITH RELIEF CAVITY | 2 |
| 02-0297 | 22 | VALVE 4-WAY 03 C 2-POS | 5 |
| 02-0310 | 23 | TEE 3/4 NPTF | 4 |
| 02-0316 | 24 | PLUG 3/4 NPT | 1 |
| 02-0326 | 25 | HOSE END 3/4 WB X 3/4 NPTM | 2 |
| 02-0329 | 26 | HOSE END 1/2 WB X 1/2 NPTM | 6 |
| 02-0339 | 27 | ADAPTER 1 1/4 NPTF X 1 1/2 NPTM | 1 |
| 02-0555 | 28 | ELL 1/2 NPTM X 1/2 NPTM | 4 |
| 02-0558 | 29 | FLANGE C62 2 WELD | 1 |
| 02-0560 | 30 | TEE 2 WELDF SCH 160 | 1 |
| 02-0565 | 31 | FLANGE C61 1 1/4 SPLIT | 2 |
| 02-0571 | 32 | ADAPTER 1 1/4 WELDF X 1 1/2 WELDM SCH160 | 2 |
| 02-0578 | 33 | ADAPTER 1 1/4 NPTF X 2 NPTM | 2 |
| 02-0591 | 34 | ADAPTER 2 1/2 FM X 3 NPTM | 2 |
| 02-0603 | 35 | ADAPTER 1 NPTF X 1 1/4 NPTM | 2 |
| 02-0607 | 36 | TUBING END 3/8 X 6 ORM | 2 |
| 02-0612 | 37 | CLAMP TUBE 3/8 WELD | 6 |

Power Unit Reference Numbers - 2 x 30 HP (Continued)

| Part # | Ref.# | Description | Qty. |
|---------|-------|--|------|
| 02-0616 | 38 | ADAPTER 1/4 NPTF X 4 ORM | 2 |
| 02-0629 | 39 | TUBING END 3/8 X 3/8 NPTM 90 | 2 |
| 02-0687 | 40 | TUBING END 3/8 X 3/8 NPTM 90 | 2 |
| 02-0697 | 41 | ELL 12 ORM X 12 JICM | 2 |
| 02-0698 | 42 | HOSE END 3/4 WB X 12 JICF | 2 |
| 02-0804 | 43 | OIL COOLER AOCH-25-3 208-230/460 60HZ | 1 |
| 02-0805 | 44 | COUPLING 2 SCH 40 | 2 |
| 02-0823 | 45 | CLEAN OUT COVER 14 | 3 |
| 02-0824 | 46 | CLEAN OUT COVER MNTG BRKT REMOVABLE | 3 |
| 02-0859 | 47 | VALVE CHECK 3/8 NPTF AIR BLEED | 2 |
| 02-0871 | 48 | ELL 4 WELD 90 SCH 40 | 1 |
| 02-0872 | 49 | FLANGE C61 4 WELD 500 PSI | 1 |
| 02-0878 | 50 | FLANGE C61 1 SPLIT W/BOLTS | 2 |
| 02-0879 | 51 | HOSE END 1 WB X 1 F61 SPT 90 | 2 |
| 02-0881 | 52 | ADAPTER 1 1/2 WELDF X 2 WELDM | 2 |
| 02-0904 | 53 | PLUG 3 NPT SQ HD | 1 |
| 02-1062 | 54 | FLANGE C61 1 1/4 WELD COMP W61-20-20 | 2 |
| 02-1098 | 55 | HOSE END 1 1/4 WB X 1 1/4 F6190 5000 | 2 |
| 02-2255 | 56 | ADAPTER 1 NPTM X 1 NPTF SWV | 1 |
| 02-2330 | 57 | CLAMP HOSE 1 WB W/RUBBER INS. | 2 |
| 02-3064 | 58 | CLAMP PIPE 2 STAUFF WELD | 1 |
| 02-3076 | 59 | HOSE END 1 WB X 1 NPTM | 4 |
| 02-3107 | 60 | VALVE BALL 1 NPTF W/ HANDLE | 2 |
| 02-3540 | 61 | FLANGE C61 1 1/2 X 1 NPT W/BOLTS | 2 |
| 02-3560 | 62 | MANIFOLD ASSEMBLY F/TR-12 100A TR-10 100 (RE | 1 |
| 02-3884 | 63 | O-RING 1/8 X 1.5 ID F/ 1 1/4 FLANGE | 2 |
| 02-4079 | 64 | BOLT KIT F/ 2 CODE 62 FLANGE | 1 |
| 02-4253 | 65 | FILTER BREATHER BAYONET FLANGE 2 INCH | 2 |
| 02-4254 | 66 | FILTER BREATHER BASKET 2 INCH | 2 |
| 02-4328 | 67 | FILTER BREATHER BAYONET ADAPTER F/ 02-3229 | 2 |
| 02-4330 | 68 | FILTER BREATHER SPIN ON VICKERS V0211B1R03 | 2 |
| 02-4331 | 69 | CAP 2 NPT SCH 40 | 1 |
| 02-4417 | 70 | TUBING END 3/8 X 1/4 NPTM | 2 |
| 02-4472 | 71 | ADAPTER 4 ORF X 6 ORM K&R6410-6-4 | 4 |
| 02-4582 | 72 | PUMP 69 GPM PISTON HP LIMITEDW/ 12 VANE KAWA | 2 |
| 02-4584 | 73 | HOSE END 2 1/2 BARB X 2 1/2 F61 90 | 2 |


Power Unit Reference Numbers - 2 x 30 HP (Continued)

| Part # | Ref.# | Description | Qty. |
|---------|-------|--|------|
| 02-4585 | 74 | ADAPTER 4 NPTF X 5 NPTF SCH 40 | 2 |
| 02-4586 | 75 | HOSE END 2 1/2 BEADED X 2 1/2NPTM 90 | 2 |
| 02-4587 | 76 | 1 X SCH40 X 27 PIPE | 1 |
| 02-4588 | 77 | FILTER SUCTION 3 100 GPM 100 MESH TANK MOUNT | 2 |
| 02-4589 | 78 | 5 X SCH40 X 25 PIPE | 2 |
| 02-4590 | 79 | HUB COUPLING 1 3/4-7/16 X 1 7/8-1/2 M500U IN | 2 |
| 02-4591 | 80 | ADAPTER PUMP/MTR SAE D4 X 286TC 8 1/2 | 2 |
| 02-4593 | 81 | VALVE CHECK FLG MTD 1 1/4 C62BODY INSERTA IC | 2 |
| 02-4594 | 82 | VALVE CHECK INSERT USE W/02-4593 INSERTA ICS | 2 |
| 02-4595 | 83 | FILTER RETURN LINE 1 1/2 NPTF6 MICRON TANK M | 1 |
| 02-4596 | 84 | VALVE 2-WAY 4 ORF PORTS NO 120 VAC | 2 |
| 02-4597 | 85 | NIPPLE 4 ORM ADJUSTABLE | 2 |
| 02-4604 | 86 | HOSE END 1 1/4 WB X 1 1/4 F6290 | 2 |
| 02-4606 | 87 | CLAMP HOSE FOR 2.5 ID 3.0625 OD SUCTION HOSE | 4 |
| 02-4607 | 88 | FLANGE C62 1 1/4 SPLIT | 4 |
| 02-4608 | 89 | VALVE RELIEF 1 1/4 C62 80 GPM | 2 |
| 02-4609 | 90 | FLANGE C61 2 1/2 SPLIT W/ BOLT KIT | 2 |
| 03-1179 | 91 | MOTOR 30 HP 1760 208-230/460V286TC TEFC SP | 2 |
| 03-3689 | 92 | SWITCH LEVEL PLUG ADAPTER 1 1/4 | 1 |
| 05-0061 | 93 | BOLT 1/2-13 X 1 1/4 HEX HD GR2 | 20 |
| 05-0064 | 94 | WASHER 1/2 LOCK | 12 |
| 05-0075 | 95 | NUT 1/2-13 HEX SELF-LOCKING | 14 |
| 05-0096 | 96 | BOLT3/8-16 X 1 HEX HD | 4 |
| 05-0105 | 97 | NUT 5/16-18 HEX SELF-LOCKING | 4 |
| 05-0145 | 98 | BOLT 1/4-20 X 1 1/2 ALLEN HD | 8 |
| 05-0148 | 99 | BOLT 1/2-13 X 1 | 6 |
| 05-0154 | 100 | BOLT 5/16-18 X 2 1/4 ALLEN HD | 4 |
| 05-0212 | 101 | BOLT 10/24 X 1 1/4 ALLEN HD | 20 |
| 05-0226 | 102 | WASHER 3/4 LOCK | 8 |
| 05-0521 | 103 | WASHER 1/2 LOCK GRADE 8 HI-COLLAR80-0123 | 8 |
| 05-2276 | 104 | BOLT 1/2-13 X 6 1/2 ALLEN HEAD | 8 |
| 05-2557 | 105 | BOLT 3/4-10 X 1 3/4 HX HD GD 5 | 8 |
| 06-0011 | 106 | DECAL MOTOR ROTATION 3/4 X 4 | 2 |
| 09-4837 | 107 | 7GA X 13-1/2 X 30-1/8 | 1 |
| 09-5847 | 108 | 1 1/4 X SCH160 X 4 PIPE SQ CUT | 2 |
| 14-2239 | 109 | 1/2 X 2 BAR X 2-11/16 | 4 |

Power Unit Reference Numbers - 2 x 30 HP (Continued)

| Part # | Ref.# | Description | Qty. |
|---------|-------|--|------|
| 28-1366 | 110 | 1 X SCH40 X 23 PIPE | 2 |
| 28-1869 | 111 | 7GA X 13 X 14-3/4 | 2 |
| 29-5510 | 112 | 4 X SCH40 X 29 PIPE | 1 |
| 29-5526 | 113 | 4 X SCH40 X 21-1/2 PIPE SQ CUT | 1 |
| 29-6008 | 114 | 2 X SCH160 X 40-3/4 PIPE SQ CUT | 1 |
| 29-6066 | 115 | 1/2 X SCH40 X 24 PIPE | 3 |
| 29-6067 | 116 | 3/4 X SCH40 X 25 PIPE | 3 |
| 29-6090 | 117 | 1/4 X SCH80 X 10 PIPE | 1 |
| 29-6554 | 118 | 1 X SCH40 X 24 PIPE | 2 |
| 99-7009 | 119 | SWITCH OIL LEVEL & TEMP NC UPTL008180F | 1 |
| 02-4605 | 120 | HOSE 2 1/2 SUCTION | 7 |
| 02-0880 | 121 | HOSE 1 WB 4000PSI | 14 |
| 02-0327 | 122 | HOSE 3/4 2WB 3100 PSI | 6 |
| 02-0335 | 123 | HOSE 1 1/4 WIRE BRAID 5000 | 8 |
| 02-0608 | 124 | TUBING 3/8 OD .049 WALL | 22 |
| 02-0330 | 125 | HOSE 1/2 WB 3500PSI | 3 |

Switch Location Diagram



Switch Description


- 1) **Proximity Switch, Bale Counter** - Mounted adjacent to bale length counter wheel. This proximity switch sends a signal to PLC input that controls bale length. Each pulse represents approximately 1 inch.
- 2) **Interlock Switch with Key** - Mounted next to hopper access door. This switch is used as a safety measure to prevent the machine from operation if and when the hopper door is opened.
- 3) **Tie Position and Ram Extended Proximity Switch** - These switches supply information to the PLC when the ram is in the TIE POSITION or EXTENDED position.
- 4) **Rear Proximity Switch** - Mounted at rear of baler. When this switch is actuated, ram stops its rearward movement and will stop or start forward, depending on control conditions.
- 5) **Twister Counter Proximity Switch** - This switch is mounted directly over twister hydraulic motor drive gear and senses and counts rotations of motor by means of a actuator pad welded onto the gear. The LED indicator on the switch should be illuminated when twister gear slots are open. This switch sends pulses or counts to the processor and controls tie operation. When twister stops in proper position, LED will be lit, otherwise machine will fault to prevent damage to twister/tier mechanism.
- 6) **Tier Forward and Rear Limit Switches** - These switches control travel of tier inserter.
- 7) **Bale Length Counter Proximity** - This proximity Switch signals the PLC one count when each gear tooth passes the proximity switch.
- 8) **Photocell Switch For Autocycle Mode** - This proximity switch will start or continue to operate baler if the photocell detects material in the feed hopper. (The baler must be in "AUTOCYCLE MODE" for this switch to function).

Twister Head Clock Adjustment - Left Hand Assembly

Note: The procedure below is for TIEger Auto-Tie balers with a left hand twister assembly only. The procedure for balers with right hand twister assemblies can be found on the next page. To assess the misalignment of the twister heads, look at the top twister head (A). The condition shown in the diagram below indicates that the top twister head is misaligned, indicated by the downward position of the tie slot (C), which needs to be adjusted to the horizontal position (B), as shown.

Adjustment Procedure:

- 1) Loosen the 2 bolts (see diagram below) on the proximity bracket (D).
- 2) Adjust proximity switch (E) to the left to adjust the twister head upward or to the right to adjust the twister head downward (the amount of adjustment should be done in increments of 1/16" or less at a time).
- 3) Once the twister head slot reaches the horizontal position (B), then retighten the 2 bolts that secure the proximity bracket (D).




Twister Head Clock Adjustment - Right Hand Assembly

Note: The procedure below is for TIEger Auto-Tie balers with a right hand twister assembly only. The procedure for balers with left hand twister assemblies can be found on the previous page. To assess the misalignment of the twister heads, look at the top twister head (A). The condition shown in the diagram below indicates that the top twister head is misaligned, indicated by the downward position of the tie slot (C), which needs to be adjusted to the horizontal position (B), as shown.

Adjustment Procedure:

- 1) Loosen the 2 bolts (see diagram below) on the proximity bracket (D).
- 2) Adjust proximity switch (E) to the left to adjust the twister head upward or to the right to adjust the twister head downward (the amount of adjustment should be done in increments of 1/16" or less at a time).
- 3) Once the twister head slot reaches the horizontal position (B), then retighten the 2 bolts that secure the proximity bracket (D).



Twister Assembly

Electrical Schematic

Refer to the electrical and hydraulic schematics shipped with your open end auto-tie baler or contact Marathon Equipment Company at 1-800-633-8974 and ask to speak with the Field Service Department.

Please have model and serial number available when you call.

Electrical Charts

| Motor Size | VAC | Total Full Load Amp | Dual Element Fuse Max Size | Circuit Breaker Max Size |
|---|-----|---------------------|----------------------------|--------------------------|
| 30 HP Main Motor | 208 | 88 | 150 | 200 |
| | 230 | 82 | 150 | 200 |
| | 460 | 40 | 70 | 100 |
| | 575 | 32 | 60 | 80 |
| 2 x 30 HP Main Motor 1 HP Fan Cooler | 208 | 180.6 | 225 | 300 |
| | 230 | 164.2 | 200 | 250 |
| | 460 | 82.1 | 110 | 125 |
| | 575 | 65.7 | 80 | 110 |


Spare Parts List

| Part # | Qty | Description |
|---------|-----|--|
| 02-0214 | 1 | VALVE RELIEF 20 GPM CART PILOT OP |
| 02-0700 | 1 | GAUGE PRESSURE 1/4 NPTM 0-5000 W/ORIFICE |
| 02-4330 | 1 | FILTER BREATHER SPIN ON VICKERS V0211B1R03 |
| 02-4414 | 1 | FILTER ELEMENT 6 MICRON F/ 02-4324 VICKERS |
| 02-4512 | 1 | COIL F/VICKERS VALVE D03 DIN CONNECTION 115AC |
| 03-0010 | 1 | LIMIT SWITCH ARM WITH ROLLER |
| 03-0012 | 1 | LIMIT SWITCH 5 DEGREE PRE-TRAVEL |
| 03-0433 | 1 | TRANSDUCER 0-4000 PSI 1-11 VDC |
| 03-0476 | 1 | FUSE 3 AMP DUAL 1 1/4 BUSS |
| 03-0735 | 3 | FUSE 2 AMP AGC STYLE |
| 03-0798 | 1 | FUSE 1 AMP AGC STYLE 250 VOLT |
| 03-1179 | 1 | MOTOR 30 HP 1760 RPM 208/230/460 VOLT |
| 03-4152 | 1 | RELAY SAFETY MONITORING 3 OUTPUT |
| 03-4216 | 1 | PHOTO CELL HARSH DUTY RECEIVER 24VDC SM30PRL |
| 99-8222 | 1 | PHOTO CELL HARSH DUTY EMITTER SMA30PEL |
| 03-4229 | 1 | SWITCH INTERLOCK OMRON D4BS-3AFS |
| 03-4189 | 1 | SWITCH PROXIMITY 12MM 10-30VDC SOURCING |
| 03-4252 | 1 | SWITCH PROXIMITY 30MM NO 6-48VDCSOURCING 28MM RANGE |
| 03-4264 | 1 | TRANSDUCER CURRENT 0-10VDC 100,150,200A |
| 03-4313 | 1 | SWITCH PROXIMITY 18MM 10-30VDC SOURCING 8MM RANGE |
| 03-4364 | 1 | LIMIT SWITCH 2 NO 2 NC MAKE IN BOTH DIRECTIONS |
| 03-4392 | 1 | SWITCH PROXIMITY 30MM NC 6-48VDCSOURCING 28MM RG |
| 03-0935 | 2 | KEY |
| 80-0060 | 2 | WIRE FEED TENSION ROLLER |
| 05-4368 | 2 | WIRE FEED GUIDE CERAMIC |
| 05-4468 | 2 | WIRE FEED GUIDE CERAMIC .200 ID |
| 05-3656 | 5 | BALE WIRE 11 GA 100 POUND BOX BLACK ANNEALED NON-OIL |
| 28-8621 | 1 | ROLLER, WIRE INSERTER NEEDLE |
| 28-8362 | 1 | TWISTER HEAD |
| 06-2789 | 2 | WIRE CUTTER |
| 05-4420 | 2 | BOLT FOR WIRE CUTTER 10-32 X 3/4 |
| 03-5266 | 3 | SWITCH PROXIMITY |

See the following pages for tier components diagrams and parts lists. To order replacement parts please contact your distributor or Marathon Equipment directly at 1-800-633-8974, M-F 8am-4:30pm CST.

Insertor Needle Assembly

Refer to the parts list on the next page.




Insertor Needle Assembly - Parts List

| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 294432 | 1 | 3 X 1 X .120 X 75 3/4 TUBING | 5 |
| 288613 | 2 | 1/2 PL X 2 5/8 X 8 1/4 | 5 |
| 288614 | 3 | 1/2 X 8 X 36 BAR | 1 |
| 288615 | 4 | 1/2 X 8 X 31 1/4 BAR | 1 |
| 288617 | 5 | UHMW 1/2 X 2 X 8 | 1 |
| 286008 | 6 | L2 X 2 X 1/4 X 8 | 1 |
| 288616 | 7 | 3/8 X 1 X 8 BAR | 5 |
| 288618 | 8 | UHMW 1/4 X 1 1/2 X 8 | 10 |
| 288619 | 9 | 1/4 X 1 X 8 BAR | 5 |
| 303763 | 10 | 3/8 PL X 3 X 6 3/8 | 5 |
| 288621 | 11 | NEEDLE ROLLER 3 DIA X 3/4 WITH | 5 |
| 800186 | 13 | BOLT SHOULDER 3/8 X 3/4 | 5 |
| 050025 | 14 | NUT 1/4-20NC HEX SELF-LOCKING | 15 |
| 053222 | 15 | BOLT 1/4 -20 X 1 FSHCS GR 5 | 12 |
| 050052 | 17 | WASHER 1/2 FLAT | 24 |
| 050018 | 18 | NUT 1/2-13 HEX SELF-LOCKING | 12 |
| 050319 | 19 | BOLT 1/2- 13 X 1 3/4 HHCS GR 8 | 2 |
| 054358 | 20 | BOLT 1/2- 13 X 6 HHCS GRD 8 (M | 2 |
| 288622 | 21 | 1/4 X 2 X 1 7/8 BAR | 5 |
| 052193 | 22 | BOLT 1/2- 1 3 X 5 1/2 HHCS GR | 8 |

Twister Head Assembly

Refer to the parts list on the next page.



Twister Head Assembly - Parts List

| Part # | Ref # | Description | Qty |
|---------|-------|---------------------------------|-----|
| 29-6729 | 1 | 5/8 PL X 20 X 36 | 1 |
| 29-6730 | 2 | 5/8 PL X 20 X 36 | 1 |
| 30-8748 | 3 | 1 X 2 X 20 BAR | 2 |
| 29-0627 | 4 | 3/4 X 2 X 2 1/4 BAR | 1 |
| 29-7166 | 5 | 1 X 2 X 6 BAR | 2 |
| 29-0629 | 6 | 3/4 X 2 X 6 1/2 BAR | 2 |
| 29-0630 | 7 | 3/4 X 2 X 6 BAR | 2 |
| 05-4350 | 8 | GEAR SPUR 64T 14.5PD 6DP 1 1/2 | 3 |
| 05-4422 | 9 | BEARING: NICE 7516 DLTN FOR 5 T | 6 |
| 05-4363 | 10 | WASHER THRUST IGLIDE THERMOPLA | 6 |
| 05-4416 | 14 | GEAR SPUR 16T 2.666PD 6DP 1 1/ | 5 |
| 05-4360 | 15 | BUSHING 660 BRONZE 5 1/2 OD(| 10 |
| 28-8362 | 16 | TWISTER HEAD, CUT SIDE | 5 |
| 29-0206 | 17 | TWISTER HEAD, GUIDE SIDE | 5 |
| 05-4417 | 18 | BOLT 1/4 -28 X 1 FSHCS | 20 |
| 29-7155 | 19 | 2 PL X 5 1/2 X 5 1/2 | 1 |
| 02-4618 | 20 | MOTOR HYDRAULIC PARKER TG0785U | 1 |
| 05-0339 | 21 | BOLT 1/2- 13 X 3 SHCS GR 5 | 4 |
| 05-0521 | 22 | WASHER 1/2 LOCK GRADE 8 HI-COL | 4 |
| 05-4544 | 23 | GEAR SPUR 16T 2.666PD 1 1/2 FA | 1 |
| 05-4559 | 24 | BOLT 5/8-18 X 3/4 SHCS | 1 |
| 05-4558 | 26 | REST BUTTON 1/2 X 1/2 MMC# 851 | 1 |
| 29-6181 | 27 | 5/8 PL X 2 1/2 X 2 1/2 | 4 |
| 06-2904 | 28 | UHMW 1 1/2 X 4 3/16 X 6 | 4 |
| 05-0276 | 29 | BOLT 3/8-16 X 1 1/4 FSHCS | 32 |
| 05-3222 | 30 | BOLT 1/4 -20 X 1 FSHCS GR 5 | 16 |
| 29-0713 | 32 | 3/8 X 1 1/2 X 1 1/2 BAR | 2 |
| 05-4367 | 33 | DOWEL PIN 3/16 X 1/2 | 4 |
| 29-0714 | 34 | 11 GA HI TEN X 1 1/2 X 2 5/8 | 2 |
| 05-3665 | 35 | BOLT 1/4- 20 X 1/2 SHCS | 4 |
| 29-0715 | 36 | 11 GA HI TEN X 1 X 1 1/2 BAR | 3 |
| 29-6789 | 37 | 1 CR X 5 ROD | 2 |
| 05-0293 | 38 | WASHER 5/8 FLAT | 1 |
| 05-3538 | 39 | COTTER PIN 3/16 X 2 | 4 |
| 05-4365 | 40 | DOWEL PIN 1/4 X 5/8 | 20 |
| 29-0711 | 41 | 1 G&P X 4 ROD | 3 |
| 29-0712 | 42 | 1/4 PL X 3 O.D. X 1 I.D. | 3 |
| 05-0069 | 43 | WASHER FLAT 1 CAD PLT | 3 |
| 05-2307 | 44 | BOLT 3/8-16 X 1 SHCS | 3 |
| 30-8747 | 50 | 1/2 X 2 X 1 1/4 BAR | 1 |
| 05-4366 | 51 | BOLT 1/4 -28 X 1/2 FSHCS | 40 |


Refer to the parts list on the next page.



Drive Assembly For Twister Head - Parts List


| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 800065 | | BEARING 2 OD X 1 ID PRESS FIT | 2 |
| 801674 | | LINK CONNECTING FULL F/ 50-2 C | 1 |
| 800139 | 1 | 1/2 X 4 X 10 1/2 BAR | 1 |
| 800156 | 2 | UHMW 3 1/4 X 3/8 ROD | 1 |
| 054549 | 3 | SPROCKET D50BS20HX1 1/4 5/16 K | 1 |
| 800180 | 4 | UHMW 3 1/4 X 1/16 ROD | 1 |
| 290023 | 5 | L4 X 4 X 1/2 X 2 1/4 | 2 |
| 800131 | 6 | 1 X 4 X 7 1/2 BAR | 1 |
| 800153 | 7 | 1 X 4 1/2 CR ROD SQ CUT | 1 |
| 800140 | 8 | 1/2 X 4 X 6 BAR | 1 |
| 800142 | 9 | 1/2 X 3 1/2 X 8 BAR | 1 |
| 290390 | 10 | L4 X 3 X 1/2 X 8 | 1 |
| 289020 | 11 | 3/4 PL X 9 X 10 | 1 |
| 800141 | 12 | 1/2 PL X 3 3/4 X 6 | 2 |
| 297339 | 13 | 1 3/8 PL X 6 X 8 | 1 |
| 199219 | 15 | SPROCKET TENSIONER COST MACH F | 1 |
| 024618 | 16 | MOTOR HYDRAULIC PARKER TG0785U | 1 |
| 800116 | 17 | CHAIN ROLLER RIVETED | 18 |
| 050319 | 18 | BOLT 1/2- 13 X 1 3/4 HHCS GR 8 | 10 |
| 052008 | 19 | BOLT 1/2- 13 X 1 1/2 HHCS GRD | 4 |
| 052452 | 20 | BOLT 1/2- 13 X 1 1/2 HHCS GR 8 | 4 |
| 050339 | 21 | BOLT 1/2- 13 X 3 SHCS GR 5 | 4 |
| 054372 | 22 | BOLT 3/4-10 X 5 HHCS FULL THRE | 2 |
| 052556 | 23 | NUT 3/4-10 HEX JAM GR5 | 2 |
| 052433 | 24 | NUT 3/4-10 HEX GR 5 | 2 |
| 050052 | 25 | WASHER 1/2 FLAT | 16 |
| 050064 | 26 | WASHER 1/2 LOCK | 16 |
| 050521 | 27 | WASHER 1/2 LOCK GRADE 8 HI-COL | 4 |
| 053668 | 29 | SCREW 1/4-20 X 3/4 SET | 1 |
| 223475 | 32 | 1/4 PL X 2 X 2 (1=2) | 2 |
| 054559 | 33 | BOLT 5/8-18 X 3/4 SHCS | 1 |
| 052404 | 34 | NUT 1/2-13 HEX GRADE 5 | 2 |
| 054242 | 35 | WASHER 1/2 BEVEL (MCMaster#915 | 2 |

(1 of 2) Refer to the parts list on the next page



Insertor Frame Assembly

(2 of 2) Refer to the parts list on the next page.



Insertor Frame Assembly Parts List


| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 288767 | 1 | 1/2 PL X 12 X 39 3/4 | 1 |
| 288766 | 2 | 1/2 PL X 12 X 40 3/16 | 1 |
| 294424 | 3 | 1 X 3 X 81 1/4 CR BAR | 3 |
| 288775 | 4 | 1 X 3 X 17 1/4 CR BAR | 2 |
| 291538 | 5 | 1 X 1 X 40 3/16 BAR | 2 |
| 290428 | 6 | 1 X 2 X 40 1/2 BAR | 1 |
| 294425 | 7 | 3/8 PL X 6 3/8 X 73 1/8 | 1 |
| 309053 | 8 | C6 X 13 X 93 3/4 | 1 |
| 309054 | 9 | C6 X 13 X 9 19/16 | 1 |
| 288785 | 10 | C6 X 13 X 42 5/16 | 1 |
| 294489 | 11 | UHMW 1/2 X 3 X 80 3/4 | 3 |
| 288816 | 12 | UHMW 1/2 X 3 X 17 | 2 |
| 288817 | 13 | UHMW 1/4 X 1 X 12 | 10 |
| 288818 | 14 | 1 X 1 X .12 X 40 3/16 TUBING S | 2 |
| 050276 | 15 | BOLT 3/8-16 X 1 1/4 FSHCS | 23 |
| 286238 | 16 | 5/16 X 1 1/4 X 12 BAR | 5 |
| 286239 | 17 | 1/4 X 1 1/2 X 12 BAR | 5 |
| 053222 | 18 | BOLT 1/4 -20 X 1 FSHCS GR 5 | 20 |
| 050025 | 19 | NUT 1/4-20NC HEX SELF-LOCKING | 20 |
| 288823 | 20 | 1 X 1 X 3 9/16 CR BAR | 8 |
| 050317 | 21 | BOLT 1/2-13 X 1 1/2 HHCS GR 8 | 8 |
| 050064 | 22 | WASHER 1/2 LOCK | 8 |
| 050052 | 23 | WASHER 1/2 FLAT | 30 |
| 052193 | 24 | BOLT 1/2- 1 3 X 5 1/2 HHCS GR | 10 |
| 050018 | 25 | NUT 1/2-13 HEX SELF-LOCKING | 24 |
| 286230 | 27 | L2 X 2 X 1/4 X 1 1/2 SQ CUT | 2 |
| 271794 | 28 | 1/4 PL X 1 7/8 X 1 7/8 (1=2) | 4 |
| 291543 | 30 | 1/2 PL X 3 X 38 | 4 |
| 297506 | 31 | 1/2 PL X 3 X 19 1/2 | 2 |
| 311787 | 32 | 3/8 PL X 20 1/16 X 32 | 1 |
| 290447 | 34 | 1 X 3 X 4 1/4 BAR | 2 |
| 053163 | 35 | BOLT 3/4-10 X 1 1/2 HHCS GR 8 | 4 |
| 050226 | 36 | WASHER 3/4 LOCK | 4 |
| 297434 | 39 | 3/4 PL X 3 1/4 X 7 15/16 | 1 |
| 294496 | 40 | 1 1/2 OD X .234 X 3 CDSM SQ CU | 1 |
| 309042 | 41 | 1 PL X 3 1/4 X 17 15/16 | 2 |

Insertor Frame Assembly Parts List (Continued)

| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 288849 | 42 | 3/4 PL X 3 1/2 X 4 1/8 | 1 |
| 050546 | 43 | BOLT 1-8 X 5 HHCS GR8 | 1 |
| 050533 | 44 | NUT 1-8 HEX SELF-LOCKING | 1 |
| 050069 | 45 | WASHER FLAT 1 CAD PLT | 5 |
| 288863 | 46 | 1 1/4 X 1 1/2 X 2 3/4 BAR | 1 |
| 050501 | 47 | BOLT 1/2- 13 X 3 1/2 SQHCS | 2 |
| 294429 | 49 | 3/8 PL X 2 X 3 5/8 | 2 |
| 311788 | 50 | 3/8 PL X 20 1/16 X 32 | 1 |
| 290435 | 51 | 1 1/4 X 3 CR ROD | 2 |
| 052476 | 52 | BOLT 3/8-16 X 1 1/2 HHCS GR 5 | 16 |
| 050015 | 53 | NUT 3/8-16 HEX SELF LOCKING | 16 |
| 050016 | 54 | WASHER 3/8 FLAT | 14 |
| 290436 | 55 | 1/2 X 2 X 39 3/8 BAR SQ CUT | 1 |
| 054529 | 56 | BOLT 1/2-13 X 7 ALLEN HEAD (MC | 2 |
| 226878 | 57 | 3/4 OD X .125 X 2 CDSM SQ CUT | 2 |
| 054530 | 58 | SPRING COMPRESSION .938 OD-.14 | 2 |
| 310730 | 60 | 1/2 PL X 6 1/2 X 11 3/4 SQ CUT | 1 |
| 309040 | 61 | 1/2 PL X 7 3/8 X 9 3/4 | 1 |
| 062926 | 62 | CASTER SWIVEL ADJ HEIGHT 850# | 3 |
| 316271 | 63 | 3/4 PL X 6 3/4 X 10 | 1 |
| 316272 | 64 | 3/4 PL X 6 X 10 | 1 |
| 316273 | 65 | 2 PL X 1 5/8 X 5 SQ CUT | 1 |
| 310732 | 66 | 3/8 PL X 6 9/16 X 7 7/16 | 4 |
| 297405 | 67 | 1/2 PL X 6 5/8 X 7 13/16 | 1 |
| 294431 | 71 | 1 X 11 ROD | 1 |
| 294497 | 72 | 1/4 X 1 1/2 X 3 BAR SQ CUT | 2 |
| 290438 | 74 | 1/2 X 3 X 4 1/4 BAR | 2 |
| 050159 | 75 | WASHER 3/8 LOCK | 7 |
| 290439 | 76 | 1/2 PL X 1 13/16 X 1 13/16 GUS | 2 |
| 053737 | 77 | BOLT 3/8-16 X 1 1/4 HHCS GR 8 | 2 |
| 052850 | 78 | BOLT 3/8-16 X 1 1/2 FSHCS | 2 |
| 053192 | 79 | BOLT 3/8-16 X 3 1/2 SHCS GR 88 | 4 |
| 310731 | 81 | 1/2 PL X 5 X 7 13/16 | 1 |


(1 of 2) Refer to the parts list on the next page.

(1 of 2) Refer to the parts list on the next page.



Inserters/Twister Covers

(2 of 2) Refer to the parts list on the next page.



LEFT HAND SHOWN.
RIGHT HAND OPPOSITE.

Inserters/Twister Covers Parts List


| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 308941 | 2 | 11 GA HI TEN X 47 7/16 X 62 1/ | 1 |
| 297496 | 3 | 11 GA HI TEN X 26 1/4 X 52 | 1 |
| 294522 | 4 | 1/2-#13 EXP MTL X 13 X 28 | 1 |
| 308944 | 5 | 1/2-#13 FLT EXP MTL X 40 15/16 | 1 |
| 295023 | 6 | 1/4 X 1 X 45 3/8 BAR SQ CUT | 4 |
| 295024 | 7 | 11 GA HI TEN X 48 1/4 X 71 15/ | 1 |
| 295025 | 8 | 1/2-#13 EXP MTL X 41 3/4 X 65 | 1 |
| 308942 | 9 | 11 GA HI TEN X 14 5/8 X 34 1/2 | 1 |
| 308943 | 11 | 11 GA HI TEN X 2 3/4 X 9 7/8 | 2 |
| 141284 | 12 | 1/4 X 1 X 46 1/4 BAR SQ CUT | 2 |
| 294523 | 24 | 11 GA HI TEN X 13 3/8 X 46 5/8 | 1 |
| 291622 | 25 | 1/4 X 2 X 3 5/8 BAR | 3 |
| 294524 | 26 | 11 GA HI TEN X 12 1/2 X 73 1/8 | 1 |
| 294525 | 27 | 11 GA HI TEN X 3 1/16 X 6 7/8 | 4 |
| 241012 | 28 | 1/4 X 2 X 2 BAR SQ CUT | 2 |
| 294526 | 29 | 7 GA X 16 7/8 X 73 1/8 | 1 |
| 308940 | 34 | 11 GA HI TEN X 26 7/8 X 44 1/2 | 1 |
| 290565 | 37 | 11 GA HI TEN X 7 7/8 X 15 9/16 | 1 |
| 291627 | 38 | 11 GA HI TEN X 5 3/4 X 19 7/16 | 1 |
| 052008 | 39 | BOLT 1/2- 13 X 1 1/2 HHCS GRD | 14 |
| 052404 | 40 | NUT 1/2-13 HEX GRADE 5 | 14 |
| 052850 | 41 | BOLT 3/8-16 X 1 1/2 FSHCS | 4 |
| 052016 | 42 | NUT 3/8-16 HEX | 4 |
| 050159 | 43 | WASHER 3/8 LOCK | 4 |
| 050052 | 44 | WASHER 1/2 FLAT | 11 |
| 289811 | 46 | 11 GA HI TEN X 24 9/16 X 38 1/ | 1 |
| 291477 | 47 | 11 GA HI TEN X 9 5/8 X 15 5/8 | 1 |
| 233913 | 48 | 1/4 X 1 X 16 1/2 BAR SQ CUT | 1 |
| 289814 | 49 | 1/2-#13 FLT EXP MTL X 10 3/4 X | 1 |
| 289815 | 50 | 1/2-#13 FLT EXP MTL X 4 5/8 X | 1 |
| 291478 | 51 | 11 GA HI TEN X 1 7/8 X 1 7/8 | 1 |
| 289818 | 53 | 11 GA HI TEN X 3/4 DIA | 2 |
| 289819 | 54 | 1/2 X 6 9/16 CR ROD | 2 |
| 288020 | 55 | 3/4 OD X .125 X 3 CDSM SQ CUT | 6 |
| 050565 | 56 | PIN COTTER 1/8 X 3/4 | 3 |
| 289820 | 57 | 7/16 X 10 3/16 HR ROD | 1 |

Inserters/Twister Covers Parts List (Continued)

| Part # | Ref # | Description | Qty |
|---------------|--------------|---------------------------------|------------|
| 291303 | 60 | 11 GA HI TEN X 9 1/2 X 28 7/8 | 1 |
| 291304 | 61 | 11 GA HI TEN X 5 11/16 X 15 7/8 | 2 |
| 050155 | 62 | BOLT 3/8-16 X 3/4 HHCS | 4 |
| 050030 | 64 | NUT 3/8-16 NC WELD | 4 |
| 278718 | 65 | 1/4 X 1 X 43 1/2 BAR SQ CUT | 1 |
| 310596 | 70 | 11 GA HI TEN X 22 5/16 X 46 15 | 1 |
| 054242 | 71 | WASHER 1/2 BEVEL (MCMMASTER#915 | 3 |

Wire Feed Components

Refer to the **“Wire Feed, Guides, & Tensioner Parts List”** on page 2-40.




Refer to the **“Wire Feed, Guides, & Tensioner Parts List”** on page 2-40.



Wire Tensioner Components

Refer to the parts list on the next page.



Wire Feed, Guides, & Tensioner Parts List

| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 439583 | | CYL WIRE FEED ARMS | 1 |
| 050064 | 2 | WASHER 1/2 LOCK | 8 |
| 050082 | 3 | BOLT 1/2-13 X 2 HHCS | 8 |
| 054677 | 4 | NUT 3/8-16 UNC HEX SERR FLNG | 5 |
| 052231 | 5 | BOLT 3/8-16 X 1 HHCS GR5 | 4 |
| 054766 | 6 | BOLT SHOULDER 1/2-13 X 5/8 X 1 | 5 |
| 052016 | 7 | NUT 3/8-16 HEX | 4 |
| 054332 | 8 | SPRING .08 WIRE X 3/4 OD X 2 | 5 |
| 054392 | 10 | BOLT SHOULDER 1/2 X 1 W/3/8-16 | 5 |
| 054393 | 11 | BOLT 3/8-16 X 1 3/4 FULL THR | 5 |
| 264902 | 12 | 11 GA HI TEN X 2 3/4 X 3 3/4 S | 1 |
| 308972 | 13 | 1 1/2 X 1 1/4 X 6 1/2 BAR | 5 |
| 285325 | 14 | 3/4 PL X 2 1/8 X 4 | 5 |
| 285326 | 15 | 3/4 X 4 X 3 BAR | 5 |
| 052476 | 16 | BOLT 3/8-16 X 1 1/2 HHCS GR 5 | 5 |
| 050016 | 17 | WASHER 3/8 FLAT | 4 |
| 298458 | 19 | 1/4 PL X 15 3/4 X 61 1/2 | 2 |
| 292367 | 20 | L2 X 2 X 1/4 X 39 1/16 | 2 |
| 298454 | 21 | 7 GA X 14 1/2 X 22 1/4 | 3 |
| 292368 | 22 | 2 X 2 X 2 7/8 BAR | 8 |
| 286966 | 23 | 1/2 PL X 6 5/8 X 14 1/2 SQ C | 2 |
| 292369 | 25 | L2 X 2 X 1/4 X 61 1/2 | 2 |
| 292371 | 28 | 4 X 3 X 1/4 X 44 3/4 TUBING SQ | 1 |
| 298455 | 31 | 7 GA X 14 1/2 X 22 1/4 | 3 |
| 292374 | 32 | 7 GA X 14 1/2 X 61 1/2 | 2 |
| 298456 | 33 | 7 GA X 14 1/2 X 22 1/4 | 2 |
| 298457 | 34 | 7 GA X 14 1/2 X 22 1/4 | 2 |
| 290022 | 35 | 6 OD X 5.5 ID X 1 | 10 |
| 800060 | 36 | SHEAVE 1 1/2 X 7/16 X 1/2 MC#3 | 45 |
| 063364 | 37 | PIN SPRING 1/8 DIA X 1 1/4 MC# | 5 |
| 300033 | 38 | 3/4 X 2 X 2 15/16 BAR | 5 |
| 294487 | 39 | 3/8 PL X 3 1/8 X 5 3/4 | 5 |
| 294488 | 40 | 3/8 PL X 3 1/8 X 5 3/4 | 5 |
| 054464 | 41 | BUSHING BRONZE 5/8 OD X 1/2 | 10 |
| 294181 | 42 | 2 X 2 15/16 1045 CR ROD | 5 |
| 315456 | 43 | 7/16 X 3 15/16 CR ROD | 5 |

Wire Feed, Guides, & Tensioner Parts List (Continued)

| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 054134 | 44 | BOLT 3/8-16 X 1 1/4 SHCS | 10 |
| 050159 | 45 | WASHER 3/8 LOCK | 18 |
| 054468 | 46 | CERAMIC INSERT .200 ID F/AUTO | 5 |
| 300034 | 47 | 1 X 2 15/16 CR ROD | 5 |
| 063177 | 48 | NYLATRON GSM 1/4 X 2 X 5 1/2 | 5 |
| 308915 | 49 | 2 1/2 PL X 3 1/2 X 4 1/4 | 1 |
| 308916 | 50 | 1 1/4 PL X 3 1/2 X 8 13/16 | 1 |
| 313413 | 51 | 1 1/4 PL X 5 X 7 5/8 | 1 |
| 050049 | 52 | WASHER 3/4 FLAT | 2 |
| 050226 | 53 | WASHER 3/4 LOCK | 2 |
| 054863 | 54 | BOLT 3/4-10 X 4 HHCS GR 8 FULL | 2 |
| 054782 | 55 | BUSHING BRONZE 1 ID X 1 1/4 OD | 2 |
| 308983 | 57 | 1/4 PL X 1 1/4 X 1 1/2 | 1 |
| 304312 | 58 | 1/2 PL X 2 X 32 | 1 |
| 303726 | 59 | 11 GA X 1 1/2 X 3 | 5 |
| 054326 | 60 | BOLT SHOULDER 1/2x5/8 SOC | 20 |
| 054704 | 61 | BOLT SHOULDER 1/2 X 2 1/4 MC# | 5 |
| 054706 | 62 | BOLT SHOULDER 1/2 X 1/2 MC#912 | 15 |
| 304311 | 63 | 1 PL X 2 X 10 5/8 | 5 |
| 313414 | 64 | 7 GA X 8 9/16 X 38 13/16 | 1 |
| 313415 | 65 | 7 GA X 8 15/16 X 38 1/4 | 1 |
| 313206 | 66 | 1/2-#13 EXP MTL X 6 1/2 31 3/4 | 1 |
| 221966 | 67 | 7 GA X 3 X 3 (1=2) | 1 |
| 309139 | 68 | 1/2 X 2 X 31 3/4 BAR | 2 |
| 309140 | 69 | 1/2 X 1 X 32 15/16 BAR | 4 |
| 306520 | 70 | 11 GA X 1 X 10 7/8 | 4 |
| 309141 | 71 | 5/8 PL X 4 1/2 X 39 1/8 | 2 |
| 306522 | 72 | 3/4 PL X 1 1/4 X 2 | 2 |
| 309142 | 73 | 1/4 PL X 11 3/4 X 16 1/16 | 1 |
| 309147 | 74 | 1/2 X 2 X 39 1/8 BAR | 2 |
| 054737 | 75 | BOLT 1/2-13 X 3 HHCS FULL THRD | 2 |
| 050052 | 76 | WASHER 1/2 FLAT | 6 |
| 050327 | 77 | NUT 1/2-13 HEX SELF-LOCKING | 4 |
| 306525 | 78 | 11 GA X 1 X 17 1/4 | 4 |
| 054736 | 79 | SPRING, EXTENSION, 3/4 OD X .0 | 2 |
| 054368 | 83 | CERAMIC INSERT F/AUTO TIE | 10 |

Wire Feed, Guides, & Tensioner Parts List (Continued)

| Part # | Ref # | Description | Qty |
|--------|-------|--------------------------------|-----|
| 309145 | 84 | 1/4 PL X 11 13/16 X 16 1/16 | 1 |
| 306528 | 85 | 1/4 PL X 2 3/8 X 16 1/16 | 1 |
| 309150 | 86 | 1/4 PL X 2 3/8 X 16 1/16 | 1 |
| 054144 | 87 | WELD-ON PAD EYE | 4 |
| 054679 | 88 | BOLT 1/4-20 X 1 1/2 FSHCS | 5 |
| 062970 | 89 | NYLATRON GSM 1 1/2 X 3 X 4 | 5 |
| 050547 | 90 | BOLT 5/8-11 X 2 3/4 HHCS GR 8 | 10 |
| 050293 | 91 | WASHER 5/8 FLAT | 10 |
| 050561 | 92 | WASHER 5/8 LOCK | 10 |
| 299399 | 93 | 1 1/4 X 3 X 4 BAR | 5 |
| 313294 | 94 | 3/8 X 9 CR ROD | 1 |
| 313199 | 95 | 11 GA HI TEN X 8 3/4 X 34 | 1 |
| 313200 | 96 | 1/4 X 1 1/2 X 8 3/4 BAR SQ CUT | 2 |
| 313201 | 97 | 1/4 X 1 1/2 X 33 1/2 BAR SQ CU | 2 |
| 313202 | 98 | 11 GA HI TEN X 1 X 1 SQ CUT | 1 |
| 313203 | 99 | 1/4 PL X 1 1/2 X 2 1/4 | 2 |
| 313204 | 100 | 1/4 PL X 1 1/2 X 4 | 4 |
| 050319 | 101 | BOLT 1/2- 13 X 1 3/4 HHCS GR 8 | 2 |

Troubleshooting

This section is designed to assist in the diagnostics and resolution of common system faults. It is neither expressed nor implied that this list is comprehensive in nature. Effective troubleshooting involves a thorough understanding of the machine, all components, and system processes, including electrical, mechanical, and hydraulic operations. Only factory authorized and trained personnel should be allowed to perform maintenance on this machine. If the following troubleshooting methods fail to correct the problem, then contact the service department at 1-800-633-8974.

Warning: Do not perform any inspection, maintenance, adjustment, or repair without first locking-out and tagging-out the compactor per **"Lock-Out & Tag-Out Instructions" on page 2-2.**

Troubleshooting methodology should go as follows:

- 1) Identify the problem.
- 2) Identify the faulty operation.
- 3) Compile a list of components involved in the operation.
- 4) Identify the power source for each component.
- 5) Through deduction, identify the problematic component.
- 6) Test each applicable component.

Troubleshooting - Power Unit

Only thoroughly trained and experienced service personnel should perform troubleshooting and maintenance to this baler. Do not enter baler for any reason until baler has been locked-out and tagged-out per **"Lock-Out & Tag-Out Instructions" on page 2-2.**

| Problem | Possible Cause | Solution |
|----------------------------------|-------------------------------------|--|
| MAIN MOTOR WILL NOT START OR RUN | 1) No incoming power. | 1) Check main disconnect switch. |
| | 2) No control circuit power. | 2) Check primary/secondary fuses in motor control panel. |
| | 3) Safety interlock switch. | 3) Check for open hopper door. |
| | 4) Emergency stop button depressed. | 4) Check E-Stop buttons. |
| | 5) Motor overload tripped. | 5) Reset overload on motor starter. Check current load (AMPS). |
| | 6) Electrical system malfunction. | 6) Check electrical system. |
| | 7) Programmable controller fault. | 7) Check fault lights on P.C. Make sure PLC is in RUN mode. |

Troubleshooting - Power Unit (Continued)

| Problem | Possible Cause | Solution |
|--|--|--|
| PUMP NOISE | <ol style="list-style-type: none"> 1) Oil level low. 2) Air leakage in suction line. 3) Worn pump. | <ol style="list-style-type: none"> 1) Check oil level in tank. Add if necessary. 2) Check suction line for leaks. Check pump shaft seal. 3) Repair or replace hydraulic pump. |
| MAXIMUM HYDRAULIC PRESSURE NOT OBTAINABLE | <ol style="list-style-type: none"> 1) Pressure relief set too low. 2) Cylinder bypass. 3) Worn pump. 4) Check valve on unloading valve. 5) Machine not shifting out of regen. | <ol style="list-style-type: none"> 1) Check relief valve pressure setting. 2) Check for internal cylinder leak. 3) Repair or replace hydraulic pump. 4) Repair or replace. 5) Cylinder rod relief set too low. Pressure switch or transducer malfunction. |
| COMPRESSION RAM WON'T MOVE FORWARD | <ol style="list-style-type: none"> 1) Photocell malfunction. | <ol style="list-style-type: none"> 1) Replace photocell. |
| COMPRESSION RAM WILL NOT RETRACT (AUTO/MANUAL) | <ol style="list-style-type: none"> 1) Foreign material jamming ram. 2) Compression cylinder rod puppet malfunction. 3) Compression cylinder rod end pressure puppet not opening. 4) Compression cylinder rod relief pressure set too low | <ol style="list-style-type: none"> 1) Check for foreign material wedging between ram and shear bar. 2) Check solenoid valve. Check for plugged orifice. 3) Check solenoid valve. Make sure valve spool is shifting. 4) Reset pressure to correct setting. |
| COOLER/FILTER PUMP WILL NOT START/RUN | <ol style="list-style-type: none"> 1) Motor overload tripped. 2) Cooler/filter pump fuses. 3) Electrical circuit malfunction. | <ol style="list-style-type: none"> 1) Reset overload on motor starter. Check current load (AMPS). 2) Replace blown fuses. 3) Perform electrical system check. |

Troubleshooting - Wire-Tier

Do not enter baler for any reason until baler has been locked-out and tagged-out per **"Lock-Out & Tag-Out Instructions" on page 2-2.**

| Problem | Possible Cause | Solution |
|--|--|--|
| INSERTER NEEDLES NOT CAPTURING WIRE. | 1) Wire is too low to pass over the needle head. 2) Wire is too high to be captured against the needle head roller. | 1) Adjust the Spring Feeder by loosening the Jam Nut, then loosening the Adjustment Bolt to raise the Spring Feeder to the proper height. Retighten Jam Nut. (see page 1-47) 2) Adjust the Spring Feeder by loosening the Jam Nut, then tightening the Adjustment Bolt to lower the Spring Feeder. Retighten the Jam Nut. (see page 1-47) |
| BALE WIRE BREAKING OR NOT BEING PULLED ACROSS THE BALER. | 1) Too much tension on the wire. | 1) Adjust the Wire-Tensioner by loosening the Jam Nut, then loosening the Adjustment Bolt to raise the center roller of the Wire Tensioner. Retighten Jam Nut. (see page 1-47) |
| BALE WIRE IS SLACK AND/OR BALE DENSITY IS COMPROMISED. | 1) Not enough tension on the wire. | 1) Adjust the Wire-Tensioner by loosening the Jam Nut, then tightening the Adjustment Bolt to lower the center roller of the Wire-Tensioner. Retighten Jam Nut. (see page 1-47) |

Note: In all events, check output fuses.

Troubleshooting - Baler

Do not enter baler for any reason until baler has been locked-out and tagged-out per **"Lock-Out & Tag-Out Instructions" on page 2-2.**

| Problem | Possible Cause | Solution |
|--|--|--|
| Material is getting behind the main ram. | Wiper strip is not making contact with the main ram. | Loosen the wiper strip bolts (behind the feed hopper) and lower wiper strip until it just makes contact with the top of the main ram. Tighten bolts. |

3 - INSTALLATION

General Requirements

Caution:

Review this manual before beginning installation. Study job site and installation requirements carefully to be certain all necessary safeguards and/or safety devices are provided to protect all personnel and equipment during installation and as a completed system. Special attention is directed to the extract from most current version of the American National Standards Institute Z245.5.

Operating instructions in Section one of this manual are not intended as a substitute for training and experience in proper use and safety procedures in operating this equipment.

This baler is designed for indoor use ONLY.

Marathon does not assume responsibility for installation procedures of this equipment. Conformance to applicable local, state, and federal laws concerning installation rests with customer.

This section of manual covers assembly and installation of your Auto-Tie baler. The following pages cover general installation, electrical installation and start-up instructions.

Concrete Pad or Floor

The pad or floor should be a minimum 3000 psi concrete, steel reinforced, 6" thick. It is recommended that pad or floor be flush with surrounding area.

Working clearance for the panel box must comply with state and local building codes. Allow enough space in front of bale exit for bale handling vehicle. Also, allow enough space for installation and safe operation of auto-tie mechanism.


Anchoring

Anchor baler to pad using anchor plates on each side of baler base and (8) 1" diameter anchor bolts, 5 3/4" long, Red Head type recommended. After connecting all hydraulic lines, anchor power unit (if remote power unit) to pad using (6) 3/4" anchor bolts, 5 3/4" long. Anchor bolts are not provided by Marathon Equipment Company.

Decals

Installation of baler is not complete until an inspection of warning decals has been made. All warning decals must be in place prior to operating baler. Decals should be clearly visible, legible, securely applied and in proper location. For decal description and location, see Section One of this manual. Call your distributor or Marathon Equipment Company if any of warning decals are missing or become damaged and need replacing.


Anchoring Machine



- 1) Position baler in the desired location.
- 2) With a pencil, mark the location of anchor holes.
- 3) Remove anchor to view markings.
- 4) With a masonry bit, drill into the marked area.
- 5) Insert the concrete wedge bolts into drilled holes and tap with a hammer until set.
- 6) Set anchor in place add washers and nut to each anchor and tighten with wrench.

Note: Welding anchors to body is not required.

Electrical Installation



The panel box contains high voltage components. Only authorized service personnel should be allowed inside. See **"Lock-Out & Tag-Out Instructions" on page 2-2** in the Maintenance section.

Warning: Before making any electrical connection, be sure the disconnect switch has been locked-out and tagged-out per the instructions **on page 2-2**.

Grounding Instructions

Danger: All equipment should be grounded per National Electric Code.

This appliance must be connected to a grounded, metal, permanent wiring system; or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the appliance.

If there is any doubt whether the equipment is properly grounded, a qualified electrician should be consulted.

- 1) See the fuse and circuit breaker chart (**"Electrical Charts" on page 2-21**) and the wire size chart (_____) in the Maintenance section for reference during electrical installation.
- 2) Before connecting power to baler, check incoming line voltage with a voltmeter. Also, check voltage wiring in baler panel box. If baler is not wired for correct voltage, make necessary changes before proceeding.
- 3) A lockable disconnect switch is provided on baler control panel and is sized in accordance to baler. Three phase power should be connected to top of this switch. Be careful not to let incoming wires touch each other. A properly sized equipment ground should be connected to enclosure ground lug.

Start-Up Instructions

Caution: Make sure all persons and installation materials are clear of charge box area.

- 1) After electrical connections are complete, check motor rotation by doing the following:
 - a) Turn disconnect switch to "ON" position.
 - b) Insert Control key switch and turn to "ON" position.
 - c) Touch "POWER ON" button.
 - d) Touch "MOTOR START" button for 20 seconds until motor starts then touch "MOTOR STOP" button.
 - e) Check motor rotation by ensuring the motor fan is rotating in the direction of the arrow decal on the motor. In the event this decal is missing, rotation should be clockwise looking from the motor end.
 - f) Reversing any two incoming power lines will change motor/pump rotation.

Caution: If pump rotates backward, stop immediately! Pump can be damaged if operated in reverse even for short periods of time.

- 2) With ram in full retract position, check to be sure oil reservoir is filled to 3/4 level on sight gauge (refer to maintenance chart for hydraulic oil recommendations). The hydraulic system pressure has been factory set.
- 3) This open end baler is equipped with photocells, a key type interlock on hopper door and a limit switch on the swing away tier assembly, and two limit switches on the Inserter. These items have been factory adjusted. Check proper function of each of these prior to operation start-up. See procedures in Section two of this manual.

Make sure that operators are thoroughly trained in the proper use of this equipment.

Index

A

ANSI, 1-2
Automatic Operation, 1-9
Auto-Tie Cycle, 1-46

B

Bale Length Counter, 1-42
Bale Plug Instructions, 1-43
Bale Tying (Manual), 1-10
Baler Start Up, 1-8

C

Control Panel and Panel Box, 1-7

D

Decals, 1-50

E

Electrical Charts, 2-21
Electrical Schematic, 2-21
Emergency Stop Locations, 1-6

F

Fault List, 1-21

I

Insertor Frame Assembly, 2-29
Insertor Needle Assembly, 2-23
Insertor Needle Risers, 1-49
Insertor/Twister Covers, 2-33
Installation
 Anchoring, 3-2
 Concrete Pad or Floor, 3-2
 Decals, 3-2
 Electrical, 3-4

L

Lock-Out & Tag-Out Instructions, 2-2

M

Maintenance, 2-4

P

Power Unit, 2-7

S

Screens
 Auto Menu, 1-15
 Data, 1-13, 1-15, 1-38
 Diagnostics Menus, 1-34
 Fault, 1-19
 General Setup, 1-13, 1-15, 1-22
 Grade Setup, 1-13, 1-15, 1-26, 1-42
 Input/Output Status, 1-36
 Main Menu, 1-13
 Manual Menu, 1-13, 1-15, 1-16
 Manual Motor Start, 1-14
 Security, 1-7, 1-8, 1-9, 1-12
Spare Parts List, 2-22
Specifications, 1-3
Start-Up Instructions, 3-5
Switch Location, 2-17

T

Troubleshooting, 2-43
Twister Head Assembly, 2-25
Twister Head Clock Adjustment, 2-20

W

Wire Box Loading, 1-45
Wire Feed Components, 2-37
Wire Installation & Adjustment, 1-47